

CW-90/90X

Checkweigher

Installation Manual



REVOLUTION III
SCALE SOFTWARE

RICE LAKE
WEIGHING SYSTEMS
To be the best by every measure™

105942

Contents

| | |
|--|-----------|
| About This Manual | 1 |
| 1.0 Introduction..... | 1 |
| 1.1 Operating Modes | 1 |
| 1.2 Keypad Functions | 1 |
| 1.3 Annunciators LEDs..... | 2 |
| 1.4 Bar Graph LEDs..... | 3 |
| 2.0 Installation | 4 |
| 2.1 Unpacking and Assembly | 4 |
| 2.2 Leveling | 5 |
| 2.3 Making Power Connections | 5 |
| 2.4 Enclosure Disassembly..... | 5 |
| 2.5 Load Cell Wiring | 5 |
| 2.6 Wire Specifics..... | 5 |
| 2.7 Cable Grounding | 5 |
| 2.7.1 Serial Communications | 6 |
| 2.7.2 Digital I/O | 6 |
| 2.8 Enclosure Reassembly | 7 |
| 2.9 Board Removal | 7 |
| 2.10 Battery Replacement | 7 |
| 2.11 Installing Option Cards | 7 |
| 2.12 Replacement Parts and Assembly Drawings | 9 |
| 3.0 Configuration | 13 |
| 3.1 Menu Navigation | 13 |
| 3.2 Audit Menu..... | 14 |
| 3.3 Calibration Menu | 14 |
| 3.4 Setup Menu | 16 |
| 3.4.1 SCALE Submenu | 16 |
| 3.4.2 FEATUR Submenu | 20 |
| 3.4.3 FEATUR Menu, REGULA / INDUST Submenu..... | 24 |
| 3.4.4 Serial, PFORMT, DIG I/O, VERS Submenus | 26 |
| 3.5 Test Menu | 29 |
| 3.6 Time and Date Menu | 30 |
| 3.7 ACCUM Menu | 31 |
| 3.8 BRIGHT Menu | 31 |
| 3.9 ID Menu | 31 |
| 4.0 Calibration | 33 |
| 4.1 Front Panel Calibration | 33 |
| 4.2 EDP Command Calibration..... | 34 |
| 4.3 Revolution® Calibration | 35 |
| 4.4 More About Calibration..... | 35 |
| 4.4.1 Adjusting Final Calibration | 35 |
| 5.0 Checkweigher Operation | 36 |
| 5.1 Range Mode | 36 |



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com or obtained by calling 715-234-9171 and asking for the training department.

| | | |
|------------|--|-----------|
| 5.1.1 | Value Set: Keyed | 36 |
| 5.1.2 | Value Set: Push | 37 |
| 5.2 | Target Weight Mode | 37 |
| 5.2.1 | Value Set: Keyed | 37 |
| 5.2.2 | Value Set: Push | 38 |
| 5.3 | Target Percent Mode | 38 |
| 5.3.1 | Value Set: Keyed | 38 |
| 5.3.2 | Value Set: Push | 39 |
| 5.4 | IDs | 40 |
| 5.4.1 | Setting an ID | 40 |
| 5.4.2 | Using a Stored ID | 41 |
| 5.5 | Negative Checkweighing | 41 |
| 6.0 | Serial Commands | 43 |
| 6.1 | The Serial Command Set | 43 |
| 6.1.1 | Key Press Commands | 43 |
| 6.1.2 | ID Commands | 44 |
| 6.1.3 | Reporting Commands | 44 |
| 6.1.4 | Clear and Reset Commands | 44 |
| 6.1.5 | Parameter Setting Commands | 44 |
| 6.1.6 | Normal Mode Commands | 48 |
| 6.1.7 | Unique Commands | 48 |
| 6.2 | Custom Stream Formatting | 48 |
| 7.0 | Print Formatting | 51 |
| 7.1 | Print Formatting Commands | 51 |
| 7.2 | Customizing Print Formats | 52 |
| 7.2.1 | Using the EDP Port | 52 |
| 7.2.2 | Using the Front Panel | 52 |
| 7.2.3 | Using <i>Revolution</i> ® III | 53 |
| 8.0 | WLAN Installation Instructions | 54 |
| 8.1 | Enclosure Disassembly | 54 |
| 8.2 | Installing the WLAN Option Card | 55 |
| 8.3 | Mounting the Antenna | 55 |
| 8.4 | Wireless Configuration via Serial Mode | 56 |
| 8.5 | Jumpers | 56 |
| 8.6 | WLAN Card Configuration | 56 |
| 8.7 | Enclosure Reassembly | 62 |
| 8.8 | WiPort Wireless Specifications | 62 |
| 8.9 | WiPort Technical Data | 63 |
| 8.10 | WiPort Disclaimer | 64 |
| 9.0 | Appendix | 65 |
| 9.1 | Error Messages | 65 |
| 9.2 | Using the XE EDP Command | 66 |
| 9.3 | Status Messages | 66 |
| 9.3.1 | Using the P EDP Command | 66 |
| 9.3.2 | Using the ZZ EDP Command | 66 |
| 9.4 | Continuous Output (Stream) Format | 67 |
| 9.5 | Digital Filtering | 67 |
| 9.5.1 | DIGFLx Parameters | 68 |
| 9.5.2 | DFSSENS and DFTHRHR Parameters | 68 |
| 9.5.3 | Setting the Digital Filter Parameters | 68 |
| 9.5.4 | Audit Trail Support | 68 |
| 9.6 | Regulatory Mode Functions | 69 |
| 9.7 | Updating CW-90/90X Firmware | 70 |
| 9.8 | Specifications | 72 |
| | CW-90/90X Limited Warranty | 74 |

About This Manual

This manual is intended for use by qualified service technicians responsible for installing and servicing the CW-90/CW-90X checkweighing scale.



Warning

Do not open the indicator enclosure! Refer all repairs and modifications to your distributor or qualified service technician. Ensure power is disconnected prior to installing, servicing, transporting, or storing equipment.



Authorized distributors and their employees can view or download this manual from the Rice Lake Weighing Systems distributor site at www.ricelake.com.

1.0 Introduction

The CW-90/CW-90X is a high-speed digital weight indicator and scale base programmed to compare weight readings with predetermined tolerance limits defining an “accept” band.

If the current weight reading is within the acceptable range, the green “ACCEPT” LED is illuminated. If the current weight reading is less than the acceptable range, one or more of the red “UNDER” segments is illuminated. If the current weight reading is greater than the acceptable range, one or more of the yellow “OVER” segments is illuminated.

Features include:

- Large .8” (20.3 mm) LED display with “under,” “accept,” and “over” bands
- Full numeric keypad (CW-90 only)
- Four configurable digital inputs/outputs
- Two independent communication ports (2) full duplex, (1) unidirectional active 20 mA current loop

1.1 Operating Modes

The CW-90/CW-90X has two modes of operation:

Normal (Weighing) Mode

Normal mode is the “production” mode of the indicator. The indicator displays the gross or net weight, depending on whether a tare has been entered. LED annunciators indicate the type of weight value.

Menu mode

Most of the procedures described in this manual, including configuration and calibration, require the indicator to be in *Menu* mode. To enter *Menu* mode, press the MENU key (if the Audit jumper is in the “ON” position). The indicator displays “AUDIT.”

If the Audit jumper is in the “OFF” position, remove the large fillister head screw from the bottom of the enclosure. Insert a screwdriver into the access hole and press the setup switch once to enter *Menu* mode.

1.2 Keypad Functions








| Key | Function |
|---|---|
|  | Turns the <i>CW-90/CW-90X</i> unit on/off. NOTE: If the PC jumper is set to SW, the POWER button must be used to turn the unit on and off. If the PC jumper is set to ON, the unit will automatically power on when it's plugged in and the only way to turn it off is to unplug power. |
|  | Enters Menu mode, allowing configuration if the Audit jumper is in the “ON” position. Also used as an “escape” key in Menu mode. |
|  | Sets the current gross weight to zero, provided the amount of weight to be removed or added is within the specified zero range and the scale is not in motion. The zero band is defaulted to 1.9% of full scale, but can be configured for up to 100% of full scale. NOTE: 1.9% is required for legal for trade applications. |
|  | Switches the weight display to an alternate unit. The alternate unit is defined in the Setup menu, and could be kg, g, lb, oz, or lb/oz. Conversions of the weight reading, the Tare value, the Over value, and the Under value occur when the unit of measure is changed with the Units key. |
|  | Sends “on-demand” serial information out the serial port, provided the conditions for standstill are met. |
|  | Performs one of several predetermined Tare functions dependent on the mode of operation selected in the TAREFN parameter (See Section 3.4.1 on page 16). |
|  | Allows the display of the current “over tolerance” value, or allows setting the “over tolerance” value. |

Table 1-1. Keypad functions






| Key | Function |
|---|--|
|  | Allows the display of the current “under tolerance” value, or allows setting the current “under tolerance” value. |
|  | When the MODE parameter is set to TARGWT or TARG% (see Section 3.4.2 on page 20), this key is used to acquire a weight value and assign it as the desired “target” value. The CW-90/CW-90X then computes the final over/under values using the target value and the over/under tolerance settings defined during the weighing operation. |
|  | Selects a particular over/under/tare/units register set to be retrieved and used. |
|  | Used to accept entries and move down to below parameters in Menu mode. |
|  | CW-90 only. Clear key. Used to backspace on entries |
| Numeric keypad (see Figure 1-1) | CW-90 only. Used to enter values directly. |

Table 1-1. Keypad functions



Figure 1-1. CW-90 numeric keypad

1.3 Annunciators LEDs



| LED | Description |
|--|---|
|  | <p>Zero (Center of Zero) LED</p> <p>While in gross weight display mode, this LED indicates that the current displayed weight reading is within +/-0.25 display divisions of the acquired zero, or is within the center of zero band.</p> <p>When in the net weight display mode, it indicates that the current net weight reading is within +/-0.25 display divisions of the center of net zero. A display division is the resolution of the displayed weight value, or the smallest incremental increase or decrease that can be displayed or printed.</p> <p>G/B LED Gross weight mode (or Brutto in OIML mode)</p> <p>N LED Net weight display mode.</p> <p>T LED Indicates that a tare has been acquired and stored by the system.</p> <p>PT LED Indicates that a preset tare weight has been keyed in or entered via the EDP serial port.</p> |
|  | <p>Displays which unit of measure is being used.</p> <p>% LED Percent mode</p> <p>kg LED Kilograms</p> <p>g LED Grams</p> <p>lb LED Pounds</p> <p>oz LED Ounces</p> |

Table 1-2. Annunciator LEDs

1.4 Bar Graph LEDs

The bar graph LEDs provide you with a fast way of determining if a container is too heavy (OVER), too light (UNDER), or is within an acceptable weight range (ACCEPT).




Figure 1-2. Bar graph LEDs

You can enable the UNDER and OVER lights to act as a graph as illustrated in Figure 1-2, or to appear as one a solid bar regardless to how far over/under a weighment is. This is done by accessing the Feature menu (see Section 3.4.2 on page 20).

Red Segments

When illuminated, this indicates an underweight condition; the container weighs less than the lowest acceptable value. The leftmost red segments indicate that the container weight is far below the acceptable weight band (greatly under); the rightmost segments indicate that the container weight is almost in the acceptable weight band, but still under (slightly under). Illuminating the center segments indicates middle-ground, or moderately under.

Green Segment

Indicates an acceptable value. When lit, the green segment (one solid bar) indicates that the container weight is within the actual acceptable band of weight limits.

Yellow Segments

When illuminated, this indicates an overweight condition; the container weighs more than the highest acceptable value. The rightmost yellow segments indicate that the container weight is far above the acceptable weight band (greatly over); the leftmost segments indicate that the container weight is almost in the acceptable weight band, but still over (slightly over). Illuminating the center segments indicates middle-ground, or moderately over.

2.0 Installation

This section contains instructions on unpacking and assembly, leveling, making power connections, load cell wiring, wiring standard serial port, optional network communications, wiring optional digital outputs, optional backup battery operation, board diagrams, and power-up sequence.

Caution Do not pick up the scale by the “spider” assembly which supports the platter. Lifting by the spider may damage the load cell. Lift the scale from under the base to move it. If the rear panel of the indicator is removed, align the gasket holes carefully to prevent driving a screw through the gasket and causing a leak. Tighten screws to 15 in/lbs (1.7 N-m) in alternating patterns shown Figure 2-1.




Figure 2-1. Indicator back panel screw tightening sequence

2.1 Unpacking and Assembly

The indicator head and support column or stand are shipped detached from the scale platform.

1. Remove all assemblies from the shipping carton. Notice that the head and scale platform are joined by a load cell cable. This cable is correctly wired to the load cell terminal in the indicator head. Do not pull with excessive force on the connections at either end of this cable.
2. If mounting the head onto a column, remove the platter from the scale platform and set aside.
3. Invert the platform to access the column mounting holes on the rear and bottom of the platform.
4. Position the column over the four mounting holes. Install (2) 1/4-20 x 3/4" cap screws and (2) lock washers in mounting holes on bottom side of the platform. Install (2) 1/4-20 x 1-3/4" cap screws, (2) lock washers, and (2) column supports in mounting holes on rear of platform. Install coupling nuts, counter bored end first, onto threaded stem of rubber feet. Install feet onto bottom side of the column.
5. Turn the CW-90/90X upright and replace the platter on the platform.
6. Attach indicator to the column with the two knobs and nylon washers provided. Position nylon washers between indicator enclosure and column mounting holes.




Figure 2-2. Mounting column to scale platform

2.2 Leveling

Select a location for the CW-90/90X that is reasonably level and free of vibrations and air currents. Adjust the four corner feet on the base and refer to the bubble level on the inside frame. The base should not rock and the feet should have solid contact with the surface. If using a column, adjust the two column feet until they make solid contact with the support surface.

NOTE: Ensure the nut on each foot's bolt is secured flush against the scale base.

2.3 Making Power Connections

The power source used for the CW-90 must be properly grounded to an acceptable earth ground. If the indicator is remotely mounted, the platform must be separately grounded from the chassis ground screw located on the bottom of the platform. Connect this screw with 18 gauge wire to the same earth ground system as the AC power source. Failure to ground the base may cause static buildup and incorrect weights.

NOTE: The CW-90 must be installed near an easily accessible power outlet to allow for quick disconnect in case of emergency.

2.4 Enclosure Disassembly

The indicator enclosure must be opened to connect cables for load cells, communications, and digital inputs/outputs.

Warning Before opening the unit, ensure the power cord is disconnected from the power outlet. The power outlet must be located near the indicator to allow the operator to easily disconnect power to the unit.

Ensure power to the indicator is disconnected, then place the indicator face-down on an antistatic mat. Remove the screws holding the backplate to the enclosure body, then lift the backplate away from the enclosure and set it aside.

2.5 Load Cell Wiring

On all complete units (indicator head and base), the load cell has been wired to the indicator's CPU load cell terminal at the factory. If you have purchased just the indicator head, you must wire the load cell.

Wire the cable to the CPU board's J1 connector as shown in Table 2-1. Leave any excess cable outside of the indicator head during installation

NOTE: If using a 4-wire connection, set JP1 and JP2 to ON. If using a 6-wire connection, set JP1 and JP2 to OFF.

| J1 Pin | Function |
|--------|--------------|
| 1 | + Signal |
| 2 | - Signal |
| 3 | + Sense |
| 4 | - Sense |
| 5 | + Excitation |
| 6 | - Excitation |

Table 2-1. J1 pin assignments

2.6 Wire Specifics

Wires connecting to J1, J2, J3, or J4 should adhere to the following specifications:

| Wire Range | Wire Strip Length |
|----------------------------------|-----------------------|
| 28~12 AWG stranded or solid wire | 5~6 mm (3/16" ~ 1/4") |

Table 2-2. Wire specifications for connectors

2.7 Cable Grounding

Except for the power cord, all cables routed through the cord grips should be grounded against the indicator enclosure. Do the following to ground shielded cables.

- Use the lockwashers, clamps, and keps provided in the parts kit to install grounding clamps on the enclosure studs adjacent to cord grips. Install grounding clamps only for cord grips that will be used; do not tighten nuts.
- Route cables through cord grips and grounding clamps to determine cable lengths required to reach cable connectors. Mark cables to remove insulation and shield as described below:
- For cables with foil shielding, strip insulation and foil from the cable half an inch (15 mm) past the grounding clamp (see Figure 2-3). Fold the foil shield back on the cable where the cable passes through the clamp. Ensure silver (conductive) side of foil is turned outward for contact with the grounding clamp.
- For cables with braided shielding, strip cable insulation and braided shield from a point just past the grounding clamp. Strip another half inch (15 mm) of insulation *only* to expose the braid where the cable passes through the clamp (see Figure 2-3 on page 6).
- Finish installation using cable mounts and ties to secure cables inside of indicator enclosure.




Figure 2-3. Grounding Clamp Attachment for Foil-Shielded and Braided Cabling

2.7.1 Serial Communications

Wire the serial communications cables to J2, which is Port 1 (5-wire RS-232 port). J3 is Port 2 (RS-232 and 20 mA). Connect communications cables to J2 and J3 as shown in Table 2-3.

Use cable ties to secure serial cables to the inside of the enclosure.

Port 1 supports full duplex RS-232 communications only; Port 2 provides either active 20 mA output or duplex RS-232 transmission. Both ports are configured using the SERIAL menu. See Section 3.4.4 on page 26.

| Connector | Pin | Signal | Port |
|-----------|-----|--------|------|
| J2 | 1 | Ground | 1 |
| | 2 | Ground | |
| | 3 | Tx | |
| | 4 | Rx | |
| | 5 | DTR | |
| | 6 | RTS | |
| J3 | 1 | 20mA+ | 2 |
| | 2 | Ground | |
| | 3 | Tx | |
| | 4 | Rx | |
| | 5 | CTS | |
| | 6 | RTS | |

Table 2-3. J2 and J3 pin assignments

2.7.2 Digital I/O

The Digital I/O can be configured as either digital inputs or digital outputs as determined by the DIO menu (see Section 3.4.4 on page 26). The inputs are active (on) with low voltage (0 VDC) and can be driven by TTL or 5V logic without additional hardware. Use the DIG I/O menu (see Section 3.4.4 on page 26) to configure the digital inputs. LEDs on the CPU board light when digital inputs are active (see Figure 2-4).

Digital outputs are typically used to control relays that drive other equipment. Outputs are designed to sink not source, switching current. Each output is a normally open connector circuit, capable of sinking 24 mA when active. Digital outputs are wired to switch relays when the digital output is active (low, 0 VDC) with reference to 5 VDC supply. LEDs on the CPU board light up when the digital outputs are active (see Figure 2-4).




Figure 2-4. Digital I/O lights and screw locations

| Connector | Pin | Signal |
|-----------|-----|-----------|
| J4 | 1 | +5V |
| | 2 | Ground |
| | 3 | DIG I/O 1 |
| | 4 | DIG I/O 2 |
| | 5 | DIG I/O 3 |
| | 6 | DIG I/O 4 |

Table 2-4. J4 Pin Assignments (Digital I/O)

2.8 Enclosure Reassembly

Once the cabling is complete, position the backplate over the enclosure and reinstall the screws. Use the torque pattern shown in Figure 2-1 on page 4 to prevent distortion. Torque to 15 in/lbs (1.7 N-m).

2.9 Board Removal

If you must remove the CW-90/90X CPU board, use the following procedure:

1. Disconnect power to the indicator. Remove backplate as described in Section 2.4 on page 5.
2. Disconnect power supply cable from connector J9 on the CW-90/90X CPU board.
3. Disconnect the wires at the following connectors: J1, J2, J3, J4.
4. There are two boards: the CPU board and the keypad display board. Remove the five screws connecting the CPU board (see Figure 2-4), then lift the board out of the enclosure.

To replace the CPU board, reverse the above procedure. Be sure to reinstall cable ties to secure all cables inside the indicator enclosure.

2.10 Battery Replacement



Caution

Risk of explosion if battery is replaced with incorrect type.

Dispose of batteries per manufacturer instructions.

The lithium battery on the CPU board maintains the real-time clock and protects data stored in the system RAM when the indicator is not connected to AC power. Data protected by this battery includes time and date, IDs, and configuration information. If any data is lost, the indicator configuration can be restored from the PC. Watch for the low battery warning on the LCD display and periodically check the battery voltage on the CPU board. Batteries should be replaced when the indicator low battery warning comes on, or when battery voltage falls to 2.2 VDC. Life expectancy of the battery is 10 years. Use *Revolution III* to store a copy of the configuration before attempting to replace the battery.

For best results, replace the battery while in weigh mode and with AC power applied. Use care not to bend the battery retaining spring.

2.11 Installing Option Cards



Caution

Option cards are not hot-pluggable. Disconnect power cord entirely before installing option cards.

NOTE: Ethernet port is not suitable for connection to circuits used outside the building and is subject to lightning or power faults.

Each option card is shipped with installation instructions specific to that card. For specific instructions on the WLAN card, refer to Section 8.0 on page 54.

The general procedure for all option cards is:

1. Disconnect power cord from the indicator.
2. Remove the backplate as described in Section 2.4.
3. Install the plastic standoffs in the standoff holes (shown as black-shaded circles in Figure 2-5).
4. Carefully align the option card connector with the J5 connector on the CPU board.
5. Press down firmly to seat the option card in the CPU board connector.
6. Make connections to the option card as required. Use cable ties to secure loose cables inside the enclosure. When installation is complete, reassemble the enclosure as described in Section 2.8.




Figure 2-5. CW-90/90X CPU board

| Jumper | Description |
|---------|--|
| JP1/JP2 | Jump excitation to sense. If using a 4-wire load cell cable, leave JP1 and JP2 on. If using a 6-wire load cell cable, take JP1 and JP2 off. Default is ON. |
| JP3/JP4 | Used when upgrading firmware. The jumpers should be on when upgrading firmware and off when the update is complete. |
| PC | Power control. If the jumper is set to SW, the POWER key can be used to turn the unit on/off. If set to ON, the unit will power on when plugged in and can only be powered off by unplugging. |
| JMP1 | If set to Audit ON, calibration and configuration can be accessed through the front keypad. If set to Audit OFF, calibration and configuration can only be accessed by removing the screw on the base of the unit and pressing the Setup switch with a screwdriver. Default is Audit ON. |

Table 2-5. Jumper descriptions

NOTE: If the RESET button on the CPU board is pressed, the indicator will perform a reboot.

2.12 Replacement Parts and Assembly Drawings

| Ref Number | Part Number | Description (Quantity) |
|------------|------------------|---|
| 31 | 103610 | Knob, Black 1/4-20 (2) |
| 30 | 103988 | Washer, Nylon .52 ID x (2) |
| 13 | 104914 104915 | Overlay, Membrane Switch (CW-90) Overlay, Piezo (CW-90X) |
| -- | 105945 | Parts Kit, CW-90/90X (1) |
| 18 | 105976 | Cable ASSY, Power Supply (1) |
| 19A | 102354 | CPU (1) |
| 19B | 105741 | Display (1) |
| 3 | 14621 | Nut, Kep 6-32NC HEX (2) |
| 11 | 14626 | Nut, Kep 8-32NC HEX (3) |
| 16 | 14822 | Screw, MACH 4-40NCx1/4 (6) |
| 17 | 14825 | Screw, MACH 4-40NCx1/4 (4) |
| 27 | 14862 | Screw, MACH 8-32NCx3/8 (4) |
| 10 | 15134 | Washer, Lock NO 8 Type A (3) |
| 34 | 16861 | Label, Warning High (1) |
| 9 | 16892 | Label, Earth Ground (1) |
| 29 | 29635 | Stand, Tilt SST (1) |
| 21 | 42640 | Screw, MACH 1/4-28NF X 1/4 (1) |
| 22 | 44676 | Washer, Bonded Sealing (1) |
| 28 | 45042 | Washer, Bonded Sealing SST (4) |
| 12 | 45043 | Wire, Ground 4in W/No.8 (1) |
| -- | 50425 | Carton, 13.14x9.00x7.11 (1) |
| -- | 53452 | Insert, Carton N.J. D/C (1) |
| 8 | 58983 | Cable Grip, SL-7 w/Nut (3) |
| 6 | 68599 | Seal Ring, Nylon PG-11 (1) |
| 5 | 68600 | Cord Grip, PG11 (1) |
| 7 | 68601 | Nut, PG11 (1) |
| 20 | 69291 | Battery, 3v Coin Lithium (1) |
| 15 | 76556 | Power Supply, Switching (1) |
| 24 | 84388 | Gasket, Backplate 420 (1) |
| 4 | 85202 85203 | Power Cord ASSY, 120VAC (1) Power Cord ASSY, 230VAC (1) |
| 25 | 88733 | Vent, Breather Sealed (1) |
| 26 | 88734 | Nut, Breather Vent (1) |
| -- | 107476 | Bench Scale Foot |
| -- | 105555 | Coupling Nut for Feet and Overload Stops |

Figure 2-6. CW-90/90X replacement parts

| Scale Capacity | Load Cell Part Number |
|----------------|-----------------------|
| 5 lb | 107174 |
| 10 lb | 107174 |
| 25 lb | 107175 |
| 50 lb | 107176 |
| 100 lb | 107177 |

Table 2-6. CW-90X Load Cells

| Scale Capacity | Load Cell Part Number |
|----------------|-----------------------|
| 5 lb | 107756 |
| 10 lb | 107757 |
| 25 lb | 107758 |
| 50 lb | 107759 |
| 100 lb | 107760 |

Table 2-7. CW-90 Load Cells




Figure 2-7. CW-90/90X front view




Figure 2-8. CW-90/90X assembly and components




Figure 2-9. CW-90/90X dimensions

3.0 Configuration

To set up and configure the CW-90/90X checkweigher, you will either use the Menu key on the front panel or press the setup switch on the bottom of the indicator. The indicator is defaulted at the factory with the audit trail jumper (JMP1) in the ON position, allowing configuration access by pressing the Menu key. Pressing the Menu key will take you to the *Audit* menu selection. Use the ID (◀) and TARGET (▶) navigation keys to move to other menu selections. Use the UNDER (▽) and OVER (△) navigation keys to enter and exit menu selections, respectively.




Figure 3-1. Menu mode navigation structure

| Menu | | Function |
|--------|-------------|---|
| AUDIT | Audit Trail | Displays the legally relevant (LR) firmware version, configuration count, and calibration count. |
| CALIBR | Calibrate | Calibrates the scale. |
| SETUP | Setup | Accesses setup options for the scale, features, serial output, print format, digital inputs and outputs, and displays the version number. |
| TEST | Test | Performs a basic test on the A/D, digital inputs and outputs, communication ports, RAM, and keypad. |
| EXIT | Exit | Exits Configuration mode and returns to the weigh screen. |
| T&D | Time & Date | Allows you to view and change time and date. |
| ACCUM | Accumulator | Displays the current accumulator value. |
| BRIGHT | Brightness | Adjusts display intensity on a scale from 0 (dimnest) to 7 (brightest). |
| ID | ID | Allows you to setup or edit IDs. |

Table 3-1. Menu menu summary

3.1 Menu Navigation

Once you have entered the menus, you can use the front panel buttons to navigate. Note the looped menu structure shown in Figure 3-1. This provides a shortcut for accessing the rightmost menu items by navigating to the left, and vice-versa for the opposite side of the menu. This shortcut also holds true for sub-menu navigation.




Figure 3-2. Front Panel Key Functions in Menu mode

NOTE: During calibration, the ENTER key acts as a data entry confirmation key. It also acts as an EXECUTE key, and accepts the value if calibration was successful. On the CW-90, you can use either the ZERO or CLR key to perform a backspace.

Various keys are used as directional keys to navigate through the menus (see Figure 3-2). The ID (◀) and TARGET (▶) keys scroll left and right (horizontally) on the same menu level; OVER (△) and UNDER (▽) move up and down (vertically) to different menu levels. Each of these keys has a directional symbol indicating its menu navigation function. The ENTER key has the same function as UNDER (▽) when navigating the menu-either will move down to access sub-categories of a main menu item. When adding or editing data using the CW-90X, the OVER (△) and UNDER (▽) keys will edit the blinking digit. The ID (◀) and TARGET (▶) keys navigate to another digit. This also applies to the CW-90, whose numeric keys can be used to insert a digit to the right of the blinking digit. Press ENTER to accept the data and return to the next menu item.

NOTE: To exit Configuration and return to weighing, press the MENU key or navigate to the EXIT menu and press ENTER.

3.2 Audit Menu

The audit menu accesses audit trail support. It provides tracking information for configuration and calibration events. To prevent potential misuse, all configuration and calibration changes are counted as change events. Audit information can be printed by pressing the PRINT key while displaying the audit trail items.




Figure 3-3. Audit menu

| AUDIT Menu | |
|---------------|--|
| Parameter | Description |
| LR,V. | Legally relevant firmware version. |
| CALIB Number | Displays total calibration events. The display alternates (in one-second intervals) between CALIB and the four-digit number. |
| CONFIG Number | Displays total configuration events. The display alternates (in one-second intervals) between CFG and the four-digit number. |
| EXIT | Exits the audit trail and returns to weigh mode. |

Table 3-2. Audit menu parameters

3.3 Calibration Menu

See Section 4.0 on page 33 for calibration procedures. The *Calibration* menu can be protected by assigning a password in the Feature menu.

NOTE: When entering a floating point value, the decimal point will appear and flash on the far right (if it is not already on the screen). To move the decimal, press **ENTER**, then use the < and > keys to move the decimal to the desired location. The CW-90/90X requires the WZERO and WSPAN points to be calibrated. The linearity points are optional, but must NOT duplicate zero or span. During calibration, the ENTER key acts as a data entry confirmation key. It also acts as an EXECUTE key, and accepts the value if calibration was successful.




Figure 3-4. Calibration menu

| CALIBR Menu | | |
|-------------------------|---------------|---|
| Parameter | Choices | Description |
| Level 2 submenus | | |
| WZERO | — | Press ENTER and the A/D raw counts will be displayed. Press ENTER again to calibrate zero, or press MENU to cancel. "CALIBRATING, PLEASE WAIT" will be appear prior to automatically moving to WVAL. |
| WVAL | — | Press ENTER to display and edit the test weight value. Press ENTER again to move to WSPAN. |
| WSPAN | — | Press ENTER and the A/D raw counts will be displayed. Press ENTER to calibrate the span or press MENU to cancel. "CALIBRATING, PLEASE WAIT" will be appear prior to automatically moving to WLIN. |
| WLIN | PT->1 — PT->5 | <p>WGT 1 allows you to display and edit the test weight value. Press ENTER to edit the value.</p> <p>CAL1 allows you to calibrate and display the raw A/D value. Press TARE to perform calibration. Press ENTER to will move to the next calibration point.</p> <p>NOTE: The linearity points are optional, but must NOT duplicate zero or span. They must be between zero and span.</p> |
| REZERO | — | <p>Press ENTER to remove an offset value from the zero and span calibrations (e.g. if hooks or chains are being used during calibration).</p> <p>NOTE: Use this parameter only after WZERO and WSPAN have been set. See Section 4.1 on page 33 for more information about using this parameter.</p> |

Table 3-3. Calibration menu parameters


3.4 Setup Menu

The setup menu allows you to configure settings for the scale, features, serial port settings, print format, and digital inputs and outputs. You can also view the software and regulatory versions, and revert to default settings.

NOTE: If RANGE is displayed after a scale setup value is entered, the value is too large or small for the given parameter.

3.4.1 SCALE Submenu

Calibration can be performed in two places within the menu: the CALIBR menu shown in Figure 3-5 is an in-depth scale setup and calibration. A “quick access” calibration is shown in Figure 4-1 on page 33.



* Not legal for trade

Figure 3-5. Setup menu: Scale submenu


| SCALE Menu | | |
|-------------------------|--|---|
| Parameter | Choices | Description |
| <i>Level 3 submenus</i> | | |
| CALIBR | WZERO WVAL WSPAN WLIN REZERO | See Section 3.3 on page 14 for descriptions, and see Section 4.0 on page 33 for calibration procedures. Calibration can be performed in two places within the menu: the CALIBR menu shown in Figure 3-5 is an in-depth scale setup and calibration. A “quick access” calibration is shown in Figure 4-1 on page 33. |
| GRADS | 10000 1–100000 | Specifies the number of full scale graduations. The value entered must be in the range 1–100000 and should be consistent with legal requirements and environmental limits on system resolution. To calculate GRADS, use the formula: $GRADS = Capacity / Display Divisions$. Display divisions are specified under the FORMAT submenu. NOTE: If RANGE is displayed after the value is entered, the value is too large or small for the given parameter. |
| FORMAT | PRIMRY SEC TER | Select your primary, secondary, and tertiary units of measure. Sub-choices include lb, kg, oz, and g. Secondary and tertiary units can also be set to lb/oz (lb/oz is not legal for trade), or off. |
| ZTRKBN | 0 number | Automatically zeroes the scale when within the range specified, as long as the input is within the ZRANGE and scale is at standstill. Specify the zero tracking band in ± display divisions. Maximum legal value varies depending on local regulations. NOTE: For scales using linear calibration, do not set the zero tracking band to a value greater than that specified for the first linearization point. |
| ZRANGE | 1.900000 number | Selects the range within which the scale can be zeroed. The 1.900000 default value is ± 1.9% around the calibrated zero point, for a total range of 3.8%. Indicator must be at standstill to zero the scale. Use the default value for legal-for-trade applications. |
| MOTBAN | 1 number | Sets the level, in display divisions, at which scale motion is detected. If motion is not detected for 1 second or more, the standstill symbol lights. Some operations, including print, tare, and zero, require the scale to be at standstill. Maximum legal value varies depending on local regulations. If this parameter is set to 0 the standstill annunciator does not light; operations normally requiring standstill (zero, tare, print) are performed regardless of scale motion. If 0 is selected, ZTRKBN must also be set to 0. |
| OVRL0A | FS+2% FS+1D FS+9D FS | Overload. Determines the point at which the display blanks and an out-of-range error message is displayed. Maximum legal value varies depending on local regulations. |
| SSTIME | 10 number | Specifies the length of time the scale must be out of motion, in 0.1-second intervals, before the scale is considered to be at standstill. Values greater than 10 are not recommended. |
| SMPRAT | 30HZ 7.5HZ 15HZ 60HZ 120HZ 240HZ 480HZ 960HZ | Sample rate. Selects measurement rate, in samples per second, of the analog-to-digital converter. Lower sample rate values provide greater signal noise immunity. NOTE: Settings of 120Hz or above may be too fast to provide the desired stability in some static weighing applications. |

| SCALE Menu | | |
|------------|--|---|
| Parameter | Choices | Description |
| DFLTR 1-3 | 4 8 16 32 64 128 256 1 2 | <p>Selects the digital filtering rate used to reduce the effects of mechanical vibration from the immediate area of the scale. The overall filtering effect can be expressed by adding the values assigned to the three filter stages: DFLTR1 + DFLTR2 + DFLTR3</p> <p>See Section 9.5 on page 67 for information on digital filtering.</p> <p>Choices indicate the number of A/D conversions per update that are averaged to obtain the displayed reading. A higher number gives a more accurate display by minimizing the effect of a few noisy readings, but slows down the settling rate of the indicator.</p> |
| DFSENS | 2OUT 4OUT 8OUT 16OUT 32OUT 64OUT 128OUT | Digital filter cutout sensitivity. Specifies the number of consecutive readings that must fall outside the filter threshold (DFTHRH parameter) before digital filtering is suspended. |
| DFTHRH | NONE 2D 5D 10D 20D 50D 100D 200D 250D | Digital filter cutout threshold. Specifies the filter threshold, in display divisions. When a specified number of consecutive scale readings (DFSENS parameter) fall outside of this threshold, digital filtering is suspended. If NONE is selected, the filter is always enabled. |
| TAREFN | BOTH NOTARE PBTARE KEYED | <p>Enables or disables push-button and keyed tares. Possible values are:</p> <p>BOTH: Both push-button and keyed tares are enabled. NOTARE: No tare allowed (gross mode only) PBTARE: Push-button tares enabled KEYED: Keyed tare enabled</p> |
| PWRUPM | GO DELAY | <p>Power up mode. In GO mode, the indicator goes into operation immediately after a brief power up display test.</p> <p>In DELAY mode, the indicator performs a power up display test, then enters a 30-second warm up period. If no motion is detected during the warm up period, the indicator becomes operational when the warm up period ends; if motion is detected, the delay timer is reset and the warm up period repeated.</p> |
| ACCUM | OFF ON | Accumulator. Specifies whether the scale accumulator is enabled. If enabled, accumulation occurs whenever a print operation is performed. Scale must return to zero to re-arm a new print. |
| VISIBL | ON OFF | Scale visibility. Specifies whether weight data is displayed. Status annunciators, under/accept/over lights remain on in weigh mode even if VISIBL is set to OFF. |
| THRESH | 0 | <p>Enter a value to be used as divisions. When a value is entered, anything that would normal require the scale to reach zero before it happens/rearms (except for LFT parameters) now only needs to go below this value and then above it again.</p> <p>NOTE: If checkweighing is used, THRESH should be less than the under value or it can disable the digital I/O points from tripping.</p> |

| SCALE Menu | | |
|------------------|--|---|
| Parameter | Choices | Description |
| Level 4 submenus | | |
| PRIMARY | UNITS DECPNT DSPDIV | Allows you to set the primary units, decimal point format, and display divisions. |
| SEC | KG G LB OZ LB/OZ OFF | Allows you to set the secondary units. Decimal point format and display divisions are selected automatically. Values are kg=kilogram (default); g=gram; lb=pound; oz=ounce; lb/oz=pound/ounce; and off. NOTE: If secondary or tertiary values are changed, the stream tokens must be changed to match in order to stream secondary or tertiary. |
| TER | OFF KG G LB OZ LB/OZ | Allows you to see the tertiary units. Decimal point format and display divisions are selected automatically. Values are off (default); kg=kilogram; g=gram; lb=pound; oz=ounce; lb/oz=pound/ounce. NOTE: If secondary or tertiary values are changed, the stream tokens must be changed to match in order to stream secondary or tertiary. LB/OZ is not legal for trade. |
| WZERO | | Allows you to view or change the zero calibration a/d count value. |
| WVAL | | Allows you to view and edit the test weight value. NOTE: If RANGE is displayed after the value is entered, the value is too large or small for the given parameter. |
| WSPAN | | Allows you to view or change the span calibration a/d count value. |
| WLIN | PT->1 PT->2 PT->3 PT->4 PT->5 | Press ENTER to display and edit test weight and calibration values for up to five linearization points. Perform linear calibration only after WZERO and WSPAN have been set. |
| REZERO | | Removes offset from zero and span calibrations. |
| Level 5 submenus | | |
| UNITS | LB OZ KG G | Specifies primary units for displayed and printed weight. Values are lb=pound; oz=ounce; kg=kilogram; g=gram. |
| DECPNT | 888888 88888.8 8888.88 888.888 888880 8.88888 88.8888 | Allows you to place the decimal point position. Use the ID (<) and TARGET (>) keys to place the decimal point where desired. |
| DSPDIV | 1D 2D 5D | Display divisions. Selects the minimum division size for the primary unit's displayed weight. |

Table 3-4. Scale menu parameters

3.4.2 FEATUR Submenu



*INDUST Submenu is in Section 3.4.3 on page 24.

Figure 3-6. FEATUR submenu

| FEATUR Menu | | |
|-------------------------|---|--|
| Parameter | Choices | Description |
| Level 2 submenus | | |
| CHKWGH | MODE VALSET NEGCKW ID BUFFER LIGHTS | Selects the checkweighing mode (range, target weight, or target percent); controls how values are set; enables/disables negative checkweighing; enables/disables IDs; turns the buffer on/off; and sets the lights as a solid bar or graph representation. See Level 3 submenus. NOTE: The buffer can store approx. 64KB of information, which is 500 transactions using a format with 120 characters of output. |
| REGION | REGULA REGWRD DECFMT TIME DATE | Selects regional settings. See Level 3 submenus. |
| UID | 000000 | Sets the unit ID, a string of up to 6 characters. Since it can be entered by way of the serial port, any six ASCII characters can be used. This will be used in place of the <UID> token in a print format. The default value is "1." |
| CONSEC # | CURVAL RESVAL | Allows sequential numbering for print operations (CURVAL is the current value and RESVAL is the reset value). The consecutive number value is incremented following each print operation that includes <CN> in the ticket format. When the consecutive number is reset, it is reset to the RESVAL specified on the parameter. |
| PASSWD | CALIBR SETUP TEST T&D ID ACCUM | Creates a password to access the CALIBR, SETUP, TEST, T&D, ID, and ACCUM menus. Specify a non-zero value to restrict access to all configuration menus. Passwords can be overridden by loading new firmware or entering 999999. NOTE: Overriding passwords will clear configuration and calibration settings. To preserve settings (i.e., ID information), use Revolution III software to upload your data to a PC, then download it back to the CW-90 after the password override is performed. |
| KEYLCK | OVER UNDER ZERO UNITS PRINT TARE ID TARGET NUMBER | Disables the OVER, UNDER, ZERO, UNITS, PRINT, TARE, ID, TARGET, and/or numeric (CW-90 only) key(s). Select Lock to disable the key, and Unlock to enable the key. |
| STNDBY | 0 | Standby mode delay. Specifies the number of minutes the indicator must be inactive before entering standby mode. Valid values are 0 (off) through 255 minutes. When in standby mode, power is still supplied to the CPU and draws 1/2 of the current as when the display is powered. The annunciators are still lit, but no weight is displayed. Press any key to exit standby mode and reactivate the display. The indicator enters standby mode if no key presses, serial communications, or scale motion occur for the length of time specified in this parameter. Set to 0 to disable standby mode. NOTE: Standby mode will not be implemented if there is weight on the scale. |

Table 3-5. FEATUR submenu parameters

| FEATUR Menu | | |
|------------------|---|--|
| Parameter | Choices | Description |
| RECALL | ON OFF | ON allows the Tare, Zero, and Units values to be maintained across a power cycle. Over/Under/Target/ID values are also maintained. OFF clears the values on a power cycle. Zero is reset to calibrated zero and Units are reset to Primary. Over/Under/Target/ID values are reset as well. |
| Level 3 submenus | | |
| MODE | RANGE TARGWT TARG% | Sets checkweighing mode to range, target weight, or target percent. See Section 5.0 on page 36 for more information. |
| VALSET | KEYED PUSH BOTH RONLY | KEYED allows the operator to digitally set the Accept band tolerance values using keypad buttons while in Normal Weighing mode. PUSH prohibits the operator from digitally entering values with the keypad. Requires the operator to place actual weights on the scale, then press keypad buttons to acquire lower and upper Accept band tolerance values. BOTH is a combination mode that allows the operator to have the <i>CW-90/90X</i> acquire Accept band tolerances from actual weights on the scale, but then gives the operator an opportunity to digitally modify those values directly afterward. RONLY is a “read only” mode which allows the operator to see but not change values. |
| NEGCKW | OFF ON AUTO | Sets whether negative checkweighing mode is off, on, or is using auto-tare. |
| ID | OFF ON | Turns IDs on or off. See Section 5.4 on page 40 for more information on IDs. If IDs are turned off, the ID selection will not appear in the main menu structure. |
| BUFFER | OFF ON | Turns the buffer on or off. NOTE: The buffer can store approx. 64KB of information, which is 500 transactions using a format with 120 characters of output. |
| LIGHTS | SOLID GRAPH | Select SOLID if you want the checkweigher to display a solid light bar for over and under weights; select GRAPH if you want it to illuminate lights in increments relative to how close the weight is the acceptance band. See Section 1.4 on page 3 for an illustration of graph LEDs. |
| REGULA | NTEP CANADA REGULA NONE OIML | Regulatory mode. Specifies the regulatory agency having jurisdiction over the scale site. <ul style="list-style-type: none"> OIML, NTEP, and CANADA modes allow a tare to be acquired at any weight greater than zero. NONE allows tares to be acquired at any weight value. OIML, NTEP, and CANADA modes allow a tare to be cleared only if the gross weight is at no load. NONE allows tares to be cleared at any weight value. NTEP and OIML modes allow a new tare to be acquired even if a tare is already present. In CANADA mode, the previous tare must be cleared before a new tare can be acquired. NONE, NTEP and CANADA modes allow the scale to be zeroed in either gross or net mode as long as the current weight is within the specified ZRANGE. In OIML mode, the scale must be in gross mode before it can be zeroed; pressing the ZERO key in net mode clears the tare. INDUST provides a set of subparameters to allow customization of tare, clear, and print functions in non-legal-for-trade scale installations. The value specified for this parameter affects the function of the front panel TARE and ZERO keys. |
| REGWOR | GROSS BRUTTO | Sets the term displayed when weighing in gross mode. Selecting BRUTTO replaces the <i>Gross</i> annunciator with <i>Brutto</i> . |
| DECFMT | DOT COMMA | Specifies whether decimal numbers are displayed using a period (DOT) or a comma. |

Table 3-5. FEATUR submenu parameters

| FEATUR Menu | | |
|---|---|--|
| Parameter | Choices | Description |
| TIME | TFORMAT TSEP SET | Allows you to set the current time, and the time format and separator character. |
| DATE | DFORMAT D SEP SET | Allows you to set the current date, and date format and date separator character. |
| Level 4 submenus | | |
| TFORMAT | 12 HOUR 24 HOUR | Sets the time format as 12-hour format or 24-hour format. |
| T SEP | COLON COMMA | Sets the time separator as a colon or comma. |
| SET | 000000 | Sets the current time. |
| DFORMAT | MMDDY4 DDMMY4 Y4MMDD Y4DDMM MMDDY2 DDMMY2 Y2MMDD Y2DDMM | Sets the date format. Y4 will use a four-digit year value, such as 2009, while Y2 will use a two-digit value, such as 09. |
| D SEP | SLASH DASH SEMI | Sets the date separator as a slash, dash, or semicolon. |
| SET | 000000 | Sets the current date. |
| CALIBR SETUP TEST T&D ID ACCUM | 0 | Sets a password for the Calibrate, Setup, Test, T&D, ID, and Accum menu(s). Specify a non-zero value to restrict access. Passwords can be overridden by loading new firmware or entering 999999. NOTE: Overriding passwords will clear configuration and calibration settings. To preserve settings (i.e., ID information), use Revolution III software to your data to a PC, then load it back to the CW-90 after the password override is performed. |
| OVER UNDER ZERO UNITS PRINT TARE ID TARGET NUMBER | UNLOCK LOCK | Locks or unlocks the OVER, UNDER, ZERO, UNITS, PRINT, TARE, ID, TARGET, and numeric button(s). |

Table 3-5. FEATUR submenu parameters

3.4.3 FEATUR Menu, REGULA / INDUST Submenu




Figure 3-7. FEATUR menu, REGACY/INDUST submenu

| FEATUR Menu, REGULA / INDUST Submenu | | |
|--------------------------------------|----------------------------------|---|
| Parameter | Choices | Description |
| LEVEL 4, REGULA / INDUST submenu | | |
| SNPSHT | DISPLY SCALE | Display or Scale weight source. |
| HTARE | NO , YES | Allow tare in display hold. |
| ZTARE | NO , YES | Remove tare on ZERO. |
| KTARE | YES , NO | Always allow keyed tare. |
| MTARE | REPLAC REMOVE NOTHN | Multiple tare action. |
| NTARE | NO , YES | Allow negative or zero tare. |
| CTARE | YES , NO | Allow CLEAR key to clear tare/accumulator. |
| PRTMOT | NO , YES | Allow print while in motion. |
| PRTPPT | NO , YES | Add PT to keyed tare print. |
| PRTHLD | NO , YES | Print during display hold. |
| HLDWGH | NO , YES | Allow weighment during display hold. |
| MOTWGH | NO , YES | Allow weighment in motion. |
| OVRBAS | CALIB SCALE | Zero base for overload calculation. CALIB = Calibrate Zero SCALE = Scale Zero |

Table 3-6. REGACY / INDUST submenu parameters

| FEATUR Menu, REGULA / INDUST Submenu | | |
|--------------------------------------|---|---|
| Parameter | Choices | Description |
| LEVEL 4, REGULA / INDUST submenu | | |
| AGENCY | NTEP CANADA INDUST NONE OIML | <p>Selects the agency having jurisdiction over the scale site.</p> <ul style="list-style-type: none"> OIML, NTEP, and CANADA modes allow a tare to be acquired at any weight greater than zero. NONE allows tares to be acquired at any weight value. A tare can be cleared only if the gross weight is at no load. NONE allows tares to be cleared at any weight value. NTEP and OIML modes allow a new tare to be acquired even if a tare is already present. In CANADA mode, the previous tare must be cleared before a new tare can be acquired. NONE, NTEP and CANADA modes allow the scale to be zeroed in either gross or net mode as long as the current weight is within the specified ZRANGE. In OIML mode, the scale must be in gross mode before it can be zeroed; pressing ZERO in net mode clears the tare. INDUST provides a set of subparameters to allow customization of tare, clear, and print functions in non-legal-for-trade applications. <p>The value specified for this parameter affects the function of the front panel TARE and ZERO keys. See Section 9.6 on page 69 for more information.</p> |

Table 3-6. REGACY / INDUST submenu parameters

3.4.4 Serial, PFORMT, DIG I/O, VERS Submenus




Figure 3-8. Serial, PFORMT, DIG I/O, VERS submenus

| SETUP Menu | | |
|-------------------------|--|--|
| Parameter | Choices | Description |
| Level 2 submenus | | |
| SCALE | | Configure scale settings. See level 3 submenus for parameter descriptions. |
| FEATUR | See Section on page 17 | Set checkweighing options, region settings, view Unit ID, and set consecutive numbering. See level 3 submenus for parameter descriptions. |
| SERIAL | PORT 1 PORT 2 PORT 3 (Option Card) | Configure communications ports. See level 3 submenus for parameter descriptions. |
| PFORMT | GFMT NFMT ACCFMT STRM.FM BUF.FMT H1 H2 | Sets the print format for gross weight, net weight, accumulated weight, stream, buffer, Header 1 and Header 2. |
| DIG IO | DIO 1 DIO 2 DIO 3 DIO 4 | Assign digital input/output functions. |
| VERS | SOFTWR REG DEFAULT | Displays the software version. Displays the regulatory version. Restores settings to their default values. |
| Level 3 submenus | | |
| PORT 1 | TRIGGE BAUD BITS STOP B TERMIN EOLDLY ECHO | Specifies Port 1's mechanism for triggering a transmission of data, baud rate, bits, stop bits, termination character, end-of-line delay, and echo. See level 4 submenu for parameter descriptions. |
| PORT 2 | TRIGGE BAUD BITS STOP B TERMIN EOLDLY ECHO | Specifies Port 2's mechanism for triggering a transmission of data, baud rate, bits, stop bits, termination character, end-of-line delay, and echo. See level 4 submenu for parameter descriptions.. |
| PORT 3 | TRIGGE BAUD BITS STOP B TERMIN EOLDLY ECHO | Specifies Port 3's mechanism for triggering a transmission of data, baud rate, bits, stop bits, termination character, end-of-line delay, and echo. See level 4 submenu for parameter descriptions. |
| SOFTWR | V 1.00 | Displays the software version. |
| REG | LR, V.1.00 | Displays the legally relevant version. |
| DEFAULT | NO YES | Resets settings to default values if YES is selected. |

Table 3-7. Serial, PFORMT, DIG I/O, VERS submenu parameters

| SETUP Menu | | |
|-------------------------|--|---|
| Parameter | Choices | Description |
| Level 4 submenus | | |
| OFF | | <i>Turns the Digital input/output off.</i> |
| INPUT | OVER UNDER TARGET ID PRINT ZERO TARE UNITS ENTER CLEAR DSP ACC CLR ACC T&D DSP TAR CLR TAR KEY LCK HOLD CLR CN GRSNET | <i>Digital input functions.</i> |
| OUTPUT | FUNCTN OVER UNDER ACCEPT ZEROBD TIMER | <i>Digital output functions.</i> |
| TRIGGE | DEMAND STREAM WAITSS TARGET L-STAB OFF | DEMAND will send information out of the port only when the Print key is pressed. STREAM allows a continuous flow of information out of the port. WAITSS prints after a stable reading is reached, then rearms as soon as it goes back in motion. TARGET rearms as soon as the weight goes below the threshold, and will print when the weight goes above the threshold again. The weight must be within the target/accept range to print. L-STAB will print the last stable weight and is rearmed when the weight goes in motion. The weight must be within the target/accept range to print. |
| BAUD | 9600 19200 28800 38400 57600 115200 1200 2400 4800 | Baud rate. Selects the transmission speed for the EDP or printer port. |
| BITS | 8NONE 7EVEN 7ODD | Selects number of data bits and parity of data transmitted from the port. |
| STOP B | 1 2 | Stop bits. Sets the number of stop bits to 1 or 2. |

Table 3-7. Serial, PFORMT, DIG I/O, VERS submenu parameters

| SETUP Menu | | |
|------------|-----------------------------------|---|
| Parameter | Choices | Description |
| TERMIN | CR/LF CR | Termination character. Selects termination character for data sent from the EDP or printer port. |
| EOLDLY | 000000 | End-of-line delay. Sets the delay period, in 0.1-second intervals, from when a formatted line is terminated to the beginning of the next formatted serial output. Value specified must be in the range 0-255, in tenths of a second (10 = 1 second). NOTE: An EOL may be required for continuous transmission at slower baud rates to ensure the receiving buffer is empty before another string is transmitted |
| ECHO | ON OFF | This command enables or disables echoing of the serial commands sent to the indicator. |
| FUNCTN | OVER UNDER ACCEPT ZEROBD | Sets the digital output function. |
| TIMER | 000000 | Set the timer to 0 for output to remain on until the function state changes. Enter a value (in 20-millisecond increments, maximum 65535) to turn the digital output off after the specified time (even though the function state has not chagned). |

Table 3-7. Serial, PFORMT, DIG I/O, VERS submenu parameters

3.5 Test Menu




Figure 3-9. Test menu

| TEST Menu | | |
|-------------------------|-------------------------------------|---|
| Parameter | Choices | Description |
| Level 2 submenus | | |
| A/D | RAW ZERO SPAN mV EXCVDC | Gives details of current or live A/D counts as well as stored zero and span A/D values. Shows voltage levels for signal and excitation voltages. |

Table 3-8. TEST menu parameters


| TEST Menu | | |
|----------------------------------|--|--|
| Parameter | Choices | Description |
| DIG I/O | LOOP DIO 1 DIO 2 DIO 3 DIO 4 | Tests your digital I/O ports. If they are functioning, "PASS" is displayed. If they are not functioning, "FAIL" is displayed. NOTE: Both inputs and outputs are active low. They go to a ground state when active. <div>  Warning </div> The I/O ports become activated when the test is performed. Make sure any equipment is disconnected prior to performing this test to avoid it being inadvertently activated. |
| COMM | PORT1 PORT2 | Performs a loopback test on the serial ports. If they are functioning, "PASS" is displayed. If they are not functioning, "FAIL" is displayed. |
| RAM | TEST | Tests the unit's memory. If it is functioning, "PASS" is displayed. If it is not functioning, "FAIL" is displayed. |
| KEYPAD | TEST | Tests the unit's individual keypad buttons by displaying the name of the key pressed. If nothing is displayed, the key is not functioning. Press the Menu key to exit the test. |
| Level 3 submenus | | |
| RAW | VAL | Displays the live current raw A/D count. |
| ZERO | VAL | Displays the captured A/D Zero calibration value. |
| SPAN | VAL | Displays the captured A/D Span calibration value. |
| mV | VAL | Displays the live current millivolt signal voltage. |
| EXCVDC | VAL | Displays the current excitation voltage. |
| LOOP | TEST | Performs a loop test on dig I/O cards. |
| DIO 1 DIO 2 DIO 3 DIO 4 | STATUS | Displays the status of each individual digital I/O port. If set as input, the display shows input stats IN HI or IN LO. If set as output, pressing Enter toggles the output between HI and LO. OUT HI or OUT LO. OUT LO is active. |
| PORT1 PORT2 | TEST | Performs a loopback test on serial port 1 or 2. Connect jumper TX and RX together on port 1 or port 2 before testing. |

Table 3-8. TEST menu parameters

3.6 Time and Date Menu




Figure 3-10. Time and Date menu

3.7 ACCUM Menu

In order for the ACCUM menu to appear, ON must be selected from the SETUP » CONFIG » SCALE » ACCUM parameter (see Figure 3-5 on page 16).





Figure 3-11. ACCUM menu

3.8 BRIGHT Menu

There are eight brightness settings on the CW-90/90X (0-7). If a number greater than 7 is selected, “RANGE” will be displayed because the number is out of range.



3.9 ID Menu

In order for the ID menu to appear, ON must be selected from the SETUP » CONFIG » FEATUR » CHKWGH » ID menu (see Figure 3-6 on page 20).




Figure 3-12. ID menu

| <i>ID Menu</i> | | |
|-------------------------|---|--|
| Parameter | Choices | Description |
| Level 2 submenus | | |
| ID 1-50 | TARGET (VALUE) OVER (VALUE) UNDER (VALUE) TARE (VALUE) UNITS DESCR1 (DESCRIPTION) DESCR2 (DESCRIPTION) COPYWV CLEAR | TARGET value recalled with the ID. OVER value recalled with the ID. UNDER value recalled with the ID. TARE value recalled with the ID. UNITS selects the unit of measure for the stored ID values. DESCR1 description recalled with the ID. DESCR2 description recalled with the ID. COPYWV copies the working values of Target, Over, Under, Tare, Description 1 and 2 into the ID. CLEAR clears all values and descriptions in the ID. |

Table 3-9. ID menu parameters

4.0 Calibration

The CW-90/90X can be calibrated using the front panel, EDP commands, or Revolution® III.

NOTE: Calibration can be performed in two places within the menu: the CALIBR menu shown in Figure 4-1 and the SCALE submenu shown in Figure 3-5 on page 16. The CALIBR menu shown in Figure 4-1 is a “quick access” calibration; for more in-depth scale setup and calibration, use the menus found under SETUP»CONFIG»SCALE (see Figure 3-5 on page 16).

Calibration consists of the following steps:

- Zero calibration
- Entering the test weight value
- Span calibration
- Optional five-point linearization
- Optional rezero calibration for test weights using hooks or chains.

NOTE: The CW-90/90X requires the WZERO and WSPAN points to be calibrated. The linearity points are optional, but must NOT duplicate zero or span. During calibration, the ENTER key acts as a data entry confirmation key. It also acts as an EXECUTE key, and accepts the value if calibration was successful.




Figure 4-1. Calibration (CALIBR) menu

4.1 Front Panel Calibration

1. Press the MENU button, then press \triangleright until the display reads CALIBR (see Figure 4-1).
2. Press Enter or ∇ to go to the WZERO parameter.
3. Press Enter or ∇ to view the A/D count. Press Enter Key to Calibrate WZERO.

NOTE: If do not want to calibrate zero, press Menu to exit.

4. The indicator displays CALIBRATING, PLEASE WAIT while calibration is in progress. When complete, you are advanced to the next prompt (WVAL).

NOTE: To view the new A/D count, repeat Step 3, but instead of pressing Enter while viewing the value, press Menu to exit..

5. With WVAL displayed, press Enter to display the stored calibration weight value. Use the procedure shown in Figure 4-2 to enter the value of the test weights used for the span calibration. Press Enter to store the WVAL value and advance to WSPAN.

6. With WSPAN displayed, press Enter or ∇ to view the A/D count. Place test weights on the scale equal to WVAL. Press Enter to calibrate WSPAN.

NOTE: If do not want to calibrate span, press Menu to exit.

7. After Enter is pressed, the indicator displays CALIBRATING, PLEASE WAIT. When complete, you are advanced to the next prompt (WLIN).

NOTE: To view the new A/D count, navigate back to the WSPAN, repeat Step 6; however, instead of pressing Enter while viewing the value, press Menu to exit.

0 0 0 0 0 0

When editing numeric values, press \triangleleft or \triangleright to change the selected digit. Press \triangle or ∇ to increment or decrement the value of the selected digit. If not already on the screen, the decimal point will flash on the far right. To move the decimal, press Enter, then use \triangleleft or \triangleright to move the decimal position. Press Enter when done.

Figure 4-2. Editing procedure for numeric values

8. Five-point linearization (using the WLIN parameter) provides increased scale accuracy by calibrating the indicator at up to five additional points between the zero and span calibrations.

Linearization is optional: if you choose not to perform linearization, skip the WLIN parameter; if linearization values have previously been entered, these values are reset to zero during calibration. To perform linearization, follow the procedure below.

NOTE: The linearity points must be less than the WSPAN point.

- With WLIN displayed, Press ▽ to go to the first linearization point (PT-> 1).
 - Place test weights on the scale and press Enter.
 - Use the procedure shown in Figure 4-2 to enter the actual test weight value. The indicator will display *Press Enter Key to Calibrate WLIN*.
 - Press Enter to calibrate. The indicator displays *Calibrating, Please Wait* while calibration is in progress. When complete, the A/D count for the linear calibration is displayed. Press Enter again to advance to the next prompt (PT-> 2).
 - Repeat for up to five linearization points. To exit the linearization parameters, press △ to return to WLIN.
9. The rezero function is used to remove a calibration offset when hooks or chains are used to hang the test weights. If no other apparatus was used to hang the test weights during calibration, remove the test weights and press △ to return to the CALIBR menu.
 - With REZERO displayed, press Enter or ▽ to access the rezero function.
 - If hooks or chains were used during calibration, remove these and the test weights from the scale. The indicator will display *Press Enter Key to REZERO*.
 - With all weight removed, press Enter to rezero the scale. This function adjusts the zero and span calibration values. The indicator displays *Calibrating, Please Wait* while the zero and span calibrations are adjusted. When complete, the adjusted A/D count for the zero calibration is displayed. Press Enter, then press △ to return to the CALIBR menu.
 10. Press △ or the Menu button to return to weigh mode.

4.2 EDP Command Calibration

To calibrate the indicator using EDP commands, the indicator EDP port must be connected to a terminal or personal computer. See Section 2.7.1 on page 6 for EDP port pin assignments.

Once the indicator is connected to the sending device, do the following:

1. Place the indicator in config mode (display must read *CONFIG* - see Figure 3-5 on page 16) and remove all weight from the scale platform. If your test weights require hooks or chains, place the hooks or chains on the scale for zero calibration.
2. Send the SC.WZERO command to calibrate zero. The indicator displays *CALIBRATING, PLEASE WAIT* while calibration is in progress.
3. Place test weights on the scale and use the SC.WVAL command to enter the test weight value in the following format:
`SC.WVAL=nnnnnn<CR>`
4. Send the SC.WSPAN command to calibrate span. The indicator displays *CALIBRATING, PLEASE WAIT* while calibration is in progress.
5. Up to five linearization points can be calibrated between the zero and span calibration values. Use the following commands to set and calibrate a single linearization point:
`SC.WLIN.V1=nnnnn<CR>`
`SC.WLIN.C1<CR>`
The SC.WLIN.V1 command sets the test weight value (nnnnn) for linearization point 1. The SC.WLIN.C1 command calibrates the point. Repeat using the SC.WLIN.Vx and SC.WLIN.Cx commands as required for additional linearization points.
6. To remove an offset value, clear all weight from the scale, including hooks or chains used to hang test weights, then send the SC.REZERO command. The indicator displays *CALIBRATING, PLEASE WAIT* while the zero and span calibrations are adjusted.
7. Send the SC.KUPARROW or SC.KEXIT EDP command to return to normal mode.

4.3 Revolution® Calibration

To calibrate the indicator using Revolution, the indicator EDP port must be connected to a PC running the Revolution configuration utility.

1. Place the indicator in config mode (display reads *CONFIG*, see Figure 3-5 on page 16) and remove all weight from the scale platform.
2. From Revolution, select File»New. The *Select Indicator* dialog box appears.
3. Select CW-90 and click OK.
4. From the *Communications* menu, select Connect.
5. From the left pane, expand the *Scale* selection and click the Scale button.




Figure 4-3. Scale button

6. From the *Tools* menu, select *Calibration Wizard*.
7. Click *NEXT* to begin the Calibration Wizard.
8. Select whether you want to perform a standard calibration or a standard with multi-point linearization and click *NEXT*.
9. In the text box, enter the test weight value be used for span calibration.
10. Select the checkbox if you are using chains or hooks during the calibration, then click *NEXT*.
11. Remove all weight from the scale and click *Click to Calibrate Zero* to begin zero calibration. If your test weights require hooks or chains, place them on the scale for zero calibration.
12. When zero calibration is complete, the Calibration Wizard prompts you to place test weights on the scale. Place the test weights on the scale, then click *Click to Calibrate Span*.
13. If you chose to perform linear calibration, the Calibration Wizard now displays prompts (1–5). Enter the weight value for Linear Point #1, place test weights on scale and click *GO*. Repeat for additional linearization points, then click *NEXT*.
14. The new and old calibration settings are displayed. To accept the new values, click *Finish*. To exit and restore the old values, click *Cancel*.

4.4 More About Calibration

The following topics provide additional information about compensating for environmental factors (Section 4.4.1) and diagnostic information for determining expected zero and span coefficients.


4.4.1 Adjusting Final Calibration

Calibration may be affected by environmental factors including wind, vibration, and angular loading. For example, if the scale is calibrated with 1000 lb, a strain test may determine that at 2000 lb the calibration is 3 lb high. In this case, final calibration can be adjusted by tweaking *WVAL* to 998.5 lb. This adjustment provides a linear correction of 1.5 lb per 1000 lb.

To adjust the final calibration, return to the *WVAL* prompt and press ENTER to show the test weight value. Press Δ or ∇ to adjust calibration up or down. Press ENTER to save the value, then press Δ to return to the *CALIBR* menu.

5.0 Checkweigher Operation

The CW-90/90X can be configured for one of the three modes of operation: range, target weight, and target percent. Selecting which operation mode is done under the CHKWGH menu, MODE submenu (Figure 5-1).



If using weight on the scale to set your over/under values, select VALSET»PUSH.

If you want to manually enter your over/under values without weight on the scale, select VALSET»KEYED.

If you want to use weight on the scale to set your over/under values, but be able to edit the values captured, select VALSET»BOTH.

Figure 5-1. CHKWGH menu

5.1 Range Mode

In Range mode, the *over* and *under* values must be set.

The *Accept* band is determined as the gap between these settings.




Figure 5-2. Example of Accept band determined by under/over settings in Range mode.

5.1.1 Value Set: Keyed

To manually set the *over/under* values with no weight on the scale:

1. Press the OVER key. The OVER light begins flashing and the value with flashing digit is shown.
2. Using the Δ and ∇ keys to increment/decrement the values and the \triangleleft and \triangleright keys to move between digits, enter the desired *over* value. If using the CW-90, you can also use the numeric keypad to enter the desired *over* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

3. When the desired value is displayed, press Enter. The decimal point flashes.
4. To change the position of the decimal point, use the \triangleleft and \triangleright keys until it is in the desired position.
5. Press Enter again to accept the value and return to *weigh* mode.
6. Press the UNDER key. The UNDER light begins flashing and the value with flashing digit is shown.
7. Using the Δ and ∇ keys to increment/decrement the values and the \triangleleft and \triangleright keys to move between digits, enter the desired *under* value. If using the CW-90, you can also use the numeric keypad to enter the desired *under* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

8. When the desired value is displayed, press Enter.
The decimal point flashes.
9. To change the position of the decimal point, use the ◀ and ▶ keys until it is in the desired position.
10. Press Enter again to accept the value and return to *weigh* mode.

5.1.2 Value Set: Push

To set the *over/under* values using weight on the scale:

1. Place the weight you want to be determined as “over” on the scale.
2. Press the OVER key.
3. The weight is captured and set as the *over* value.
The display will read “Stored” and the *over* light flashes.
4. Place the weight you want to be determined as “under” on the scale.
5. Press the UNDER key.
6. The weight is captured and set as the *under* value.
The display will read “Stored” and the *under* light flashes.
7. The *Accept* band is set as the gap between the *over* and *under* settings. See Figure 5-2 for an example.

5.2 Target Weight Mode

In Target Weight mode, the *over* and *under* values can only be set by keying in the values. The VALSET parameter only pertains to setting the target weight value. The *Accept* band is determined based on a desired target weight.




Figure 5-3. Example of under/over/target settings in Target Weight mode.

5.2.1 Value Set: Keyed

1. Press the TARGET key. The Accept light begins flashing and a flashing digit is shown.
2. Using the ▲ and ▼ keys to increment/decrement the values and the ◀ and ▶ keys to move between digits, enter the desired value. If using the CW-90, you can also use the numeric keypad to enter the desired *target weight* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

3. When the desired value is displayed, press Enter.
The decimal point flashes.
4. To change the position of the decimal point, use the ◀ and ▶ keys until it is in the desired position.
5. Press Enter again to accept the value and return to *weigh* mode.
6. Press the OVER key. The Over light begins flashing and a flashing digit is shown.
7. Using the ▲ and ▼ keys to increment/decrement the values and the ◀ and ▶ keys to move between digits, enter the desired value. If using the CW-90, you can also use the numeric keypad to enter the desired *over* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

8. When the desired value is displayed, press Enter.
The decimal point flashes.
9. To change the position of the decimal point, use the ◀ and ▶ keys until it is in the desired position.
10. Press Enter again to accept the value and return to *weigh* mode.

11. Press the UNDER key. The Under light begins flashing and a flashing digit is shown.
12. Using the \triangle and ∇ keys to increment/decrement the values and the \triangleleft and \triangleright keys to move between digits, enter the desired value. If using the CW-90, you can also use the numeric keypad to enter the desired *under* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

13. When the desired value is displayed, press Enter.
The decimal point flashes.
14. To change the position of the decimal point, use the \triangleleft and \triangleright keys until it is in the desired position.
15. Press Enter again to accept the value and return to *weigh* mode.

5.2.2 Value Set: Push

1. Place the weight you want to be used as the “target” on the scale.
2. Press the Target key. The Accept light flashes and the indicator displays “STORED.” The weight has been captured and stored as the target weight.
3. Press the OVER key. The Over light begins flashing and a flashing digit is shown.
4. Using the \triangle and ∇ keys to increment/decrement the values and the \triangleleft and \triangleright keys to move between digits, enter the desired value. If using the CW-90, you can also use the numeric keypad to enter the desired *over* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

5. When the desired value is displayed, press Enter.
The decimal point flashes.
6. To change the position of the decimal point, use the \triangleleft and \triangleright keys until it is in the desired position.
7. Press Enter again to accept the value and return to *weigh* mode.
8. Press the UNDER key. The Under light begins flashing and a flashing digit is shown.
9. Using the \triangle and ∇ keys to increment/decrement the values and the \triangleleft and \triangleright keys to move between digits, enter the desired value. If using the CW-90, you can also use the numeric keypad to enter the desired *under* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

10. When the desired value is displayed, press Enter.
The decimal point flashes.
11. To change the position of the decimal point, use the \triangleleft and \triangleright keys until it is in the desired position.
12. Press Enter again to accept the value and return to *weigh* mode.

5.3 Target Percent Mode

In Target Percent mode, the *over* and *under* values can only be set by keying in the values (in percentages). The VALSET parameter only pertains to setting the target weight value. The *Accept* band is determined based on a percentage of the desired target weight.

NOTE: The % annunciator will be lit during target percent setup in menu mode, but not in weigh mode.




Figure 5-4. Example of under/over/target settings in Target Weight mode.

5.3.1 Value Set: Keyed

1. Press the TARGET key. The Accept light begins flashing and a flashing digit is shown.
2. Using the \triangle and ∇ keys to increment/decrement the values and the \triangleleft and \triangleright keys to move between

digits, enter the desired value. If using the CW-90, you can also use the numeric keypad to enter the desired *target percent* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

3. When the desired value is displayed, press Enter.
The decimal point flashes.
4. To change the position of the decimal point, use the ◀ and ▶ keys until it is in the desired position.
5. Press Enter again to accept the value and return to *weigh* mode.
6. Press the OVER key. The Over light begins flashing and a flashing digit is shown.
7. Using the △ and ▽ keys to increment/decrement the values and the ◀ and ▶ keys to move between digits, enter the desired value, in percent (entering 10 equals 10%). If using the CW-90, you can also use the numeric keypad to enter the desired *over* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

8. When the desired value is displayed, press Enter.
The decimal point flashes.
9. To change the position of the decimal point, use the ◀ and ▶ keys until it is in the desired position.
10. Press Enter again to accept the value and return to *weigh* mode.
11. Press the UNDER key. The Under light begins flashing and a flashing digit is shown.
12. Using the △ and ▽ keys to increment/decrement the values and the ◀ and ▶ keys to move between digits, enter the desired value, in percent (entering 5 equals 5%). If using the CW-90, you can also use the numeric keypad to enter the desired *under* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

13. When the desired value is displayed, press Enter.
The decimal point flashes.
14. To change the position of the decimal point, use the ◀ and ▶ keys until it is in the desired position.
15. Press Enter again to accept the value and return to *weigh* mode.

5.3.2 Value Set: Push

1. Place the weight you want to be used as the “target percent” value on the scale.
2. Press the Target key. The Accept light flashes and the indicator displays “STORED.” The weight has been captured and stored as the target percent value.
3. Press the OVER key. The Over light begins flashing and a flashing digit is shown.
4. Using the △ and ▽ keys to increment/decrement the values and the ◀ and ▶ keys to move between digits, enter the desired value, in percent (entering 10 equals 10%). If using the CW-90, you can also use the numeric keypad to enter the desired *over* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

5. When the desired value is displayed, press Enter.
The decimal point flashes.
6. To change the position of the decimal point, use the ◀ and ▶ keys until it is in the desired position.
7. Press Enter again to accept the value and return to *weigh* mode.
8. Press the UNDER key. The Under light begins flashing and a flashing digit is shown.
9. Using the △ and ▽ keys to increment/decrement the values and the ◀ and ▶ keys to move between digits, enter the desired value, in percent (entering 5 equals 5%). If using the CW-90, you can also use the numeric keypad to enter the desired *under* value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

10. When the desired value is displayed, press Enter.
The decimal point flashes.
11. To change the position of the decimal point, use the ◀ and ▶ keys until it is in the desired position.
12. Press Enter again to accept the value and return to *weigh* mode.

5.4 IDs

IDs are used to save and recall previously set over/under/tare settings, descriptions, and units preferences. The CW-90/90X has the capacity to store up to 50 individual IDs. Make sure you have IDs enabled under the CHKWGH menu shown in Figure 5-1 on page 36 or the menu will not appear.




Figure 5-5. ID menu

5.4.1 Setting an ID

1. From the ID menu, press Enter and you will be at ID1.
2. Navigate to the ID number you want to set (1-50) by using the ◀ and ▶ keys.

NOTE: All menus have wrap-around functionality. If you are at ID1 and want to access ID20, you can quickly do so by moving backwards through the menu.

3. When you have reached the ID number you want to set, press Enter to select that ID.
4. If in Target mode, “TARGET” will be displayed. If mode is not set to Target, skip to Step 8. If you do not need to adjust the value, use the ◀ and ▶ keys to move to the next parameter. To adjust the value, press Enter and use the ▲ and ▼ keys to increment/decrement the values and the ◀ and ▶ keys to move between digits. If using the CW-90, you can also use the numeric keypad to enter the desired value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

5. When the desired value is displayed, press Enter.
The decimal point flashes.
6. To change the position of the decimal point, use the ◀ and ▶ keys until it is in the desired position.
7. Press Enter again to accept the value.
8. “OVER” will be displayed. If you do not need to adjust the value, use the ◀ and ▶ keys to move to the next parameter. To adjust the value, press Enter and use the ▲ and ▼ keys to increment/decrement the values and the ◀ and ▶ keys to move between digits. If using the CW-90, you can also use the numeric keypad to enter the desired value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

9. When the desired value is displayed, press Enter.
The decimal point flashes.
10. To change the position of the decimal point, use the ◀ and ▶ keys until it is in the desired position.
11. Press Enter again to accept the value
12. “UNDER” will be displayed. Press Enter and use the ▲ and ▼ keys to increment/decrement the values and the ◀ and ▶ keys to move between digits. If using the CW-90, you can also use the numeric keypad to enter the desired value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

13. When the desired value is displayed, press Enter.
The decimal point flashes.
14. To change the position of the decimal point, use the ◀ and ▶ keys until it is in the desired position.

15. Press Enter again to accept the value
16. "TARE" will be displayed. Press Enter and use the Δ and ∇ keys to increment/decrement the values and the \triangleleft and \triangleright keys to move between digits. If using the CW-90, you can also use the numeric keypad to enter the desired value.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

17. When the desired value is displayed, press Enter.
The decimal point flashes.
18. To change the position of the decimal point, use the \triangleleft and \triangleright keys until it is in the desired position.
19. Press Enter again to accept the value
20. "UNITS" will be displayed. Press Enter and use the \triangleleft and \triangleright keys to move between units (LB, OZ, LB/OZ, OFF, KG, G).
21. When the desired unit is displayed, press Enter.
22. "DESC1" will be displayed. If you do not need to adjust the value, use the \triangleleft and \triangleright keys to move to the next parameter. To adjust the value, press Enter to create an ID description. A flashing placeholder is displayed.
23. Use the Δ and ∇ keys to increment/decrement description entry characters and the \triangleleft and \triangleright keys to move between placeholders.
24. When the desired description is displayed, press the Enter key to accept.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

25. "DESC2" will be displayed. If you do not need to adjust the value, use the \triangleleft and \triangleright keys to move to the next parameter. To adjust the value, press Enter to create a secondary ID description. A flashing placeholder is displayed.
26. Use the Δ and ∇ keys to increment/decrement description entry characters and the \triangleleft and \triangleright keys to move between placeholders.
27. When the desired description is displayed, press the Enter key to accept.

NOTE: To discard any changes and return to weigh mode, press the Menu button.

28. "COPYWV" is displayed. This feature copies the current over/under/tare values, units, description 1 and description 2 being used in normal weighing mode and saves them into the current ID number. If you do not want to copy the working values into this ID, use the \triangleleft and \triangleright keys to move to the next parameter. Press the Enter key to copy the current values into the ID. The indicator will display SAVING and return to COPYWV when complete.

5.4.2 Using a Stored ID

1. Press the ID key. The last ID being used is displayed with the leftmost digit flashing.
2. Use the Δ and ∇ keys to increment/decrement values and the \triangleleft and \triangleright keys to move between digits until the desired ID value is displayed.

NOTE: If an ID does not have values assigned to it, NO ID is displayed. The ZERO key acts as a backspace on the CW-90X. Use this key to navigate from a two-digit ID to a one-digit ID. On the CW-90, you can use the CLR or ZERO key to backspace.

3. Press Enter to start using that ID. "LOADING" is displayed and the indicator will return to weigh mode when the ID has been loaded.

5.5 Negative Checkweighing

You can use negative checkweighing if you have an item which you want to take weight away from. For example, if a product on the CW-90/90X weighs 20 pounds and you want to remove weight in 2 pound increments, with negative checkweighing enabled, the *Over* value could be set to -3 and the *Under* value could be set to -1. The *Accept* band would therefore be -2, illuminating the green LED when the desired weight is removed from the product.

NOTES: Negative checkweighing is only operable in Range mode. The Target key is not used.

When entering Over/Under values and printing, the negative symbol is not displayed. These numbers are still treated as negative values despite the symbol not being displayed.

COM port settings are limited to L-Stab, Demand (only if NEGCKW is set to ON rather than AUTO), and Wait SS (see Figure 3-8 on page 26).




Figure 5-6. CHKWGH menu

To use negative checkweighing:

1. Ensure Range is selected under *Mode* (See Figure 5-6).
2. Under the *NEGCKW* parameter, select ON or AUTO.

NOTE: If ON is selected, you have to manually tare when the Accept band is reached. If AUTO is selected, it will automatically tare when the Accept band is reached and is stable.

3. Press the OVER key.
4. Using the Δ and ∇ keys to increment/decrement the values and the \triangleleft and \triangleright keys to move between digits, enter the desired *over* value. If using the CW-90, you can also use the numeric keypad to enter the desired *over* value.

NOTE: The Over value you are entering is a negative value. However, it will appear to be a higher number than the Under value on the display because the negative symbol is not displayed. An example of Over/Under negative checkweighing values as they appear on the display would be Over: 3 (actually recorded as -3) and Under: 1 (actually recorded as -1). To discard any changes and return to weigh mode, press the Menu button.

5. When the desired value is displayed, press Enter.
The decimal point flashes.
6. To change the position of the decimal point, use the \triangleleft and \triangleright keys until it is in the desired position.
7. Press Enter again to accept the value and return to *weigh* mode.
8. Press the UNDER key.
9. Using the Δ and ∇ keys to increment/decrement the values and the \triangleleft and \triangleright keys to move between digits, enter the desired *under* value. If using the CW-90, you can also use the numeric keypad to enter the desired *under* value.

NOTE: The Under value you are entering is a negative value. However, it will appear to be a lower number than the Over value on the display because the negative symbol is not displayed. An example of Over/Under negative checkweighing values as they appear on the display would be Over: 3 (actually recorded as -3) and Under: 1 (actually recorded as -1). To discard any changes and return to weigh mode, press the Menu button.

10. When the desired value is displayed, press Enter.
The decimal point flashes.
11. To change the position of the decimal point, use the \triangleleft and \triangleright keys until it is in the desired position.
12. Press Enter again to accept the value and return to weigh mode.
13. Place the weight on the scale and press the TARE key to begin negative checkweighing.
14. Begin removing product from the scale until the *Accept* band is reached.
15. If AUTO was selected in Step 2, the weight will be tared automatically. If ON was selected, press TARE to tare the weight.
16. Repeat Steps 14-15 as needed.

6.0 Serial Commands

The CW-90/90X can be controlled by a PC or remote keyboard connected to an indicator serial port. Control is provided by a set of serial commands that can simulate front panel key press functions, display and change setup parameters, and perform reporting functions. This provides the ability to print configuration data or to save to your hard drive.

6.1 The Serial Command Set

The serial command set can be divided into five groups: key press commands, reporting commands, the RESETCONFIGURATION special function command, parameter setting commands, and transmit weight data commands. When a serial command is processed, the CW-90/90X responds with the message **OK**. The **OK** response verifies that the command was received and has been executed. If the command is unrecognized or cannot be executed, the CW-90/90X responds with **??**.

The following sections list the commands and command syntax used for each of these groups.

6.1.1 Key Press Commands

Key press serial commands (see Table 6-1) simulate pressing the keys on the front panel of the indicator. These commands can be used in both setup and normal (weighing) mode. Several of the commands serve as “pseudo” keys, providing functions that are not represented by a key on the front panel.

For example, to enter a 15-pound tare weight:

1. Type **K1** and press **ENTER** (or **RETURN**).
2. Type **K5** and press **ENTER**.
3. Type **KTARE** and press **ENTER**.

| Command | Function |
|-----------|--|
| KMENU | Press the MENU key |
| KZERO | In weighing mode, press the ZERO key |
| KUNITS | In weighing mode, press the UNITS key |
| KPRINT | In weighing mode, press the PRINT key |
| KTARE | Press the TARE key |
| KOVER | Press the OVER key |
| KUNDER | Press the UNDER key |
| KID | In weighing mode, press the ID key. In menu mode, move left in the menu. In data entry mode, move to previous digit. |
| KTARGET | Press the TARGET key |
| KGROSSNET | In weighing mode, press the GROSS/NET key (pseudo key) |

Table 6-1. Serial Key Press Commands

| Command | Function |
|------------|---|
| KGROSS | Go to gross mode (pseudo key) |
| KNET | Go to net mode (pseudo key) |
| KDISPACCUM | Display ACCUM (pseudo key) |
| KDISPTARE | Display tare (pseudo key) |
| KCLR | Press the CLEAR key |
| KCLRNCN | Reset consecutive number (pseudo key) |
| KCLRTAR | Clear tare from system (pseudo key) |
| KLEFT | In menu mode, move left in the menu |
| KRIGHT | In menu mode, move right in the menu |
| KUP | In menu mode, move up in the menu; in normal mode, scroll up to previous configured scale. |
| KDOWN | In menu mode, move down in the menu; in normal mode, scroll down to the next configured scale. |
| KSAVE | In menu mode, saves the current configuration |
| KEXIT | In menu mode, saves the current configuration then exits to normal mode |
| KCLRNV | In menu mode, clears non-volatile RAM |
| K0–K9 | Press number 0 (zero) through 9 |
| KDOT | Press the decimal point (.) |
| KENTER | Press the ENTER key |
| KLOCK | Lock specified front panel key. For example, to lock the ZERO key, enter KLOCK=KZERO. |
| KUNLOCK | Unlock specified front panel key. For example, to unlock the PRINT key, enter KUNLOCK=KPRINT. |
| KDATE | Display date (pseudo key) |
| KTIME | Display time (pseudo key) |
| KESCAPE | Exits the selected parameter. Returns to weigh mode if a parameter is not selected (functions identical to the MENU key in menu mode) |

Table 6-1. Serial Key Press Commands (Continued)

6.1.2 ID Commands

| Command | Function |
|-------------|--|
| ID.DESC1#N | (32 characters max.) (#N = ID number referenced) |
| ID.DESC2#N | (32 characters max.) |
| ID.OVER#N | (weight value) |
| ID.UNDER#N | (weight value) |
| ID.TARE#N | (weight value) |
| ID.TARGET#N | (weight value) |
| ID.UNITS#N | (same in alternate units) |
| ID.SELECT#N | Selects a new ID |
| ID.CLEAR#N | Clears a single ID |
| ID.CLRALL | Clears all IDs (only if in menu mode) |
| ID.COPYWV#N | Copies working values to a specified ID |

Table 6-2. ID Commands

6.1.3 Reporting Commands

Reporting commands send specific information to the serial port. The commands listed in Table 6-3 can be used in all modes.

| Command | Function |
|------------|---|
| DUMPALL | List all parameter values |
| DUMPAUDIT | List audit trail information |
| DUMPBUFFER | Lists buffer information |
| DUMPIDS | List all ID information |
| VERSION | Write CW-90/90X software version |
| P | Write current displayed weight with units identifier. See Section 9.3.1 on page 66. |
| ZZ | Write current weight and annunciator status. See Section 9.3.2 on page 66. |
| XE | Returns a 10-digit code representing any error conditions currently shown on the front panel. |

Table 6-3. Reporting Commands

6.1.4 Clear and Reset Commands

The following commands can be used to clear and reset the CW-90/90X:

RS: Reset system. Resets the indicator without resetting the configuration.

RESETCONFIGURATION: Restores all configuration parameters to their default values (menu mode only). The RESETCONFIGURATION function can also be initiated by pressing navigating to the **DEFAULT** parameter under the **VERS** menu and selecting **YES**. Then press **ENTER** to reset the indicator.

NOTE: All load cell calibration settings are lost when the RESETCONFIGURATION command is run.

CLEARBUFFER: Clears the buffer information.

6.1.5 Parameter Setting Commands

Parameter setting commands allow you to display or change the current value for a particular configuration parameter (Tables 6-4 through 6-9).

Current configuration parameter settings can be displayed in all modes using the following syntax: *command*<ENTER>

Most parameter values can be changed in menu mode only.

Use the following command syntax when changing parameter values: *command=value*<ENTER>, where *value* is either a number or a parameter value. Use no spaces before or after the equal (=) sign. If you type an incorrect command, the display reads ??.

For example, to set the motion band parameter to 5 divisions, type the following:

SC.MOTBAND=5<ENTER>

For parameters with selectable values, enter the command and equal sign followed by a question mark: *command=?*<ENTER> to see a list of those values. The indicator must be in menu mode to use this function.

NOTE: Some parameters are valid only if other parameters or parameter values are specified. Restrictions for front-panel configuration also apply to serial command configuration.

| Command | Description | Values |
|---|---|---|
| SC.GRADS | Graduations | 1–100000 |
| SC.ZTRKBND | Zero track band | 0, 0–100 |
| SC.ZRANGE | Zero range | 1.900000, 0–100 |
| SC.MOTBAND | Motion band | 1, 0–100 |
| SC.SSTIME | Standstill time | 1–65535 |
| SC.OVRLOAD | Overload | FS+2%, FS+1D, FS+9D, FS |
| SC.DIGFLTR1 SC.DIGFLTR2 SC.DIGFLTR3 | Digital filtering | 1, 2, 4, 8, 16, 32, 64, 128, 256 |
| SC.DFSENS | Digital filter cutout sensitivity | 2OUT, 4OUT, 8OUT, 16OUT, 32OUT, 64OUT, 128OUT |
| SC.DFTHRH | Digital filter cutout threshold | NONE, 2D, 5D, 10D, 20D, 50D, 100D, 200D, 250D |
| SC.SMPRAT | Sample rate | 30HZ, 60HZ, 120HZ, 240HZ, 480HZ, 960HZ |
| SC.PWRUPMD | Power up mode | GO, DELAY |
| SC.TAREFN | Tare function | BOTH, NOTARE, PBTARE, KEYED |
| SC.PRI.DECPNT | Primary units decimal position | 8.888888, 88.88888, 888.8888, 8888.888, 88888.88, 888888.8, 8888888, 8888880, 8888800 |
| SC.PRI.DSPDIV | Primary units display divisions | 1D, 2D, 5D |
| SC.PRI.UNITS | Primary units | lb, kg, g, oz, tn, t, gn, troyoz, troylb, lt, CUSTOM, NONE, OFF |
| SC.PRI.CUNITS | Primary custom units | Specify units if SC.PRI.UNITS=CUSTOM |
| SC.ACCUM | Accumulator enable | ON, OFF |
| SC.VISIBLE | Scale visibility | ON, OFF |
| SC.WZERO | Zero calibration | — |
| SC.WVAL | Test weight value | <i>test_weight_value</i> |
| SC.WSPAN | Span calibration | — |
| SC.WLIN.F1– SC.WLIN.F5 | Actual raw count value for linearization points 1–5 | 0–16777215 |
| SC.WLIN.V1 SC.WLIN.V5 | Test weight value for linearization points 1–5 | 0.000001–9999999 |
| SC.WLIN.C1– SC.WLIN.C5 | Calibrate linearization points 1–5 | — |
| SC.LC.CD | Deadload coefficient | — |
| SC.LC.CW | Span coefficient | — |
| SC.LC.CZ | Temporary zero | — |
| SC.REZERO | Rezero | — |

Table 6-4. SCALES Serial Commands

| Command | Description | Values |
|------------------------|----------------------------|--|
| EDP.BAUD# <i>p</i> | Port baud rate | 300, 600, 1200, 2400, 4800, 9600, 19200, 28800, 38400, 57600, 115200 |
| EDP.BITS# <i>p</i> | Port data bits/parity | 8NONE, 7EVEN, 7ODD, 8ODD, 8EVEN |
| EDP.TERMIN# <i>p</i> | Port termination character | CR/LF, CR |
| EDP.STOPBITS# <i>p</i> | Port stop bits | 2, 1 |

Table 6-5. SERIAL Port Serial Commands

| Command | Description | Values |
|---|---------------------------|--|
| EDP.ECHO# <i>p</i> | Port echo | ON, OFF |
| EDP.EOLDLY# <i>p</i> | Port end-of-line delay | 0-255 (0.1-second intervals) |
| EDP.TRIGGER# <i>x</i> | Port trigger | DEMAND, STREAM, WAITSS, TARGET, L-STAB, OFF |
| STR.POS# <i>p</i> | Custom stream identifiers | Specify replacement text for token Example: STR.PRI=L |
| STR.NEG# <i>p</i> | | |
| STR.PRI# <i>p</i> | | |
| STR.SEC# <i>p</i> | | |
| STR.TER# <i>p</i> | | |
| STR.GROSS# <i>p</i> | | |
| STR.NET# <i>p</i> | | |
| STR.TARE# <i>p</i> | | |
| STR.MOTION# <i>p</i> | | |
| STR.RANGE# <i>p</i> | | |
| STR.OK# <i>p</i> | | |
| STR.INVALID# <i>p</i> | | |
| For commands including “# <i>p</i> ”, <i>p</i> is the serial port number. | | |

Table 6-5. SERIAL Port Serial Commands (Continued)

| Command | Description | Values |
|------------|-------------------------------------|--|
| BUFFER | Turns buffer off or on | OFF, ON |
| MODE | Sets checkweighing mode | RANGE, TARGWT, TARG% |
| VALSET | Value set | KEYED, PUSH, BOTH, RONLY |
| NEGCKW | Sets negative checkweighing | OFF, ON, AUTO |
| ID | Turns IDs off or on | OFF, ON |
| LIGHTS | Sets the lights display | SOLID, GRAPH |
| CFGPWD | Configuration password | 0, 1–99999999 |
| CONSUM | Consecutive numbering | 0–9999999 |
| CONSTUP | Consecutive number start-up value | 0–9999999 |
| DATEFMT | Date format | MMDDYYYY, DDMMYYYY, YYYYMMDD, YYYYDDMM |
| DATESEP | Date separator | SLASH, DASH, SEMI |
| DECFMT | Decimal format | DOT, COMMA |
| DSPBRIGHT | Sets display intensity | 0 (dimkest), 1, 2, 3, 4, 5, 6, 7 (brightest) |
| KYBDLK | Keyboard lock (disable keypad) | OFF, ON |
| REGULAT | Regulatory compliance | NONE, OIML, NTEP, CANADA, INDUST |
| REG.HLDWGH | Allow weighment during display hold | NO, YES |
| REG.CTARE | Allow clear keyed tare | NO, YES |
| REG.HTARE | Allow tare in display hold | NO, YES |
| REG.KTARE | Always allow keyed tare | NO, YES |
| REG.MTARE | Multiple tare action | REPLACE, REMOVE, NOTHING |
| REG.NTARE | Allow negative tare | NO, YES |
| REG.ZTARE | Remove tare on ZERO | NO, YES |

Table 6-6. FEATURE Serial Commands

| Command | Description | Values |
|-------------|------------------------------------|---|
| REG.MOTWGH | Allow weighment in motion | NO, YES |
| REG.OVRBASE | Zero base for overload calculation | CALIB ZERO, SCALE ZERO |
| REG.PRTMOT | Allow print while in motion | NO, YES |
| REG.PRINTPT | Add PT to keyed tare print | NO, YES |
| REG.PRTHLD | Print during display hold | NO, YES |
| REG.SNPSHOT | Display or Scale weight source | DISPLAY, SCALE |
| REGWORD | Regulatory word | GROSS, BRUTTO |
| SD | Set date | MMDDYY, DDMMYY, YYMMDD, or YYDDMM. Enter six-digit date using the year-month-day order specified for the DATEFMT parameter, using only the last two digits of the year. |
| ST | Set time | hhmm (enter using 24-hour format) |
| TIMEFMT | Time format | 12HOUR, 24HOUR |
| TIMESEP | Time separator | COLON, COMMA |
| ZERONLY | Disable all keys except ZERO | OFF, ON |

Table 6-6. FEATURE Serial Commands (Continued)

| Command | Description | Values |
|----------|----------------------------------|---|
| GFMT.FMT | Gross demand print format string | See Section 7.0 on page 51 for information about demand print format strings. |
| NFMT.FMT | Net demand print format string | |
| ACC.FMT | Accumulator print format string | |
| STRM.FMT | Streaming Format | |
| BUF.FMT | Buffer Format | |
| HDRFMT1 | Header 1 Format | Enter the data you want displayed in Header 1 |
| HDRFMT2 | Header 2 Format | Enter the data you want displayed in Header 2 |

Table 6-7. PFORMT Serial Commands

| Command | Description | Values |
|--|-------------------------|---|
| DIO#b | Digital input function | OFF, ZERO, NT/GRS, TARE, UNITS, PRINT, ACCUM, TIMDATE, ESC, CLEAR, DSPTAR, IDKEY, KEY0–KEY9, KEYDP, ENTER, NAVUP, NAVDN, NAVLFT, NAVRG, KBDLOC, HOLD, CLRCN, GROSS, NET, PRIM, SEC, CLRTAR, CLRACC, TRIGGER |
| DIO#b | Digital output function | OVER, UNDER, ACCEPT, ZEROBD |
| Digital inputs and outputs are specified by bit number | | |

Table 6-8. DIG I/O Serial Commands

6.1.6 Normal Mode Commands

The normal mode print commands (see Table 6-9) transmit data to the serial port on demand in either setup or normal mode.

| Command | Description | Values |
|-------------|--|--|
| CONSUM | Set consecutive number | 0–9 999 999 |
| UID | Set unit ID | nnnnnnn |
| SD | Set date | MMDDYY, DDMMYY, YYMMDD, or YYDDMM. Enter six-digit date using the year-month-day order specified for the DATEFMT parameter, using only the last two digits of the year. |
| ST | Set time | hhmm (enter using 24-hour format) |
| SX#p | Start serial port streaming | OK or ?? |
| EX#p | Stop serial port streaming | The port streaming parameter (EDP.STREAM#p) for the streaming port must be set to LFT or INDUST before using these commands. An EX command sent while in menu mode does not take effect until the indicator is returned to normal mode. |
| XG | Transmit gross weight in displayed units | nnnnnn UU where nnnnnn is the weight value, UU is the units. NOTE: You can also send XGP, XGS, XGT, XTP, etc. to specify primary, secondary or tertiary (P.S.T.). |
| XN | Transmit net weight in displayed units | |
| XT | Transmit tare weight in displayed units | |
| XA | Transmit accumulator value | |
| RS | Reset system | Soft reset. Used to reset the indicator without resetting the configuration to the factory defaults. |
| BUFFER | Buffer commands | Displays on/off status of the buffer |
| DUMPBUFFER | | Reads the buffer |
| CLEARBUFFER | | Clears the entire buffer |

Table 6-9. Normal Mode Serial Commands

6.1.7 Unique Commands

| Command | Description |
|----------|---|
| EDP.PORT | Returns the port you are currently connected to |

Table 6-10. Unique commands

6.2 Custom Stream Formatting

Each port can be independently configured to stream a default frame format or can be customized to stream a user-defined format. Custom formatting is very similar to the standard print formatting described in Section 7.0 on page 51. Table 6-11 lists the format identifiers used to configure a custom stream format.

| Format Identifier | Defined By | Description |
|-------------------|-------------------------------------|--|
| <P[G N T]> | STR.POS#N STR.NEG#N | Polarity. Specifies positive or negative polarity for the current or specified (Gross/Net/Tare) weight on the source scale. Possible values are SPACE, NONE, + (for STR.POS#n), or – (for STR.NEG#n) |
| <U[P S T]> | STR.PRI#N STR.SEC#N STR.TER#N | Units. Specifies primary, secondary, or tertiary units for the current or specified weight on the source scale. |

Table 6-11. Custom Stream Format Identifiers

| Format Identifier | Defined By | Description |
|-------------------|--|--|
| <M[G N T]> | STR.GROSS#N STR.NET#N STR.TARE#N | Mode. Specifies gross, net, or tare weight for the current or specified weight on the source scale. |
| <S> | STR.MOTION#N STR.RANGE#N STR.OK#N STR.INVALID#N | Status for the source scale. Default values and meanings for each status: STR.MOTION#n M In motion STR.RANGE#n O Out of range STR.OK#n <space> OK STR.INVALID#n I Invalid |
| <CW> | — | Status of over/under/accept. O=Over, U=Under, A=Accept. |
| <B [-]n,...> | See descriptions below | Bit fields. Comma-separated sequence of bit field specifiers. Must be exactly 8 bits. Minus sign ([-]) inverts the bit. |
| B0 | — | Always 0 |
| B1 | — | Always 1 |
| B2 | Configuration | =1 if even parity |
| B3 | Dynamic | =1 if MODE=NET |
| B4 | Dynamic | =1 if COZ |
| B5 | Dynamic | =1 if standstill |
| B6 | Dynamic | =1 if gross negative |
| B7 | Dynamic | =1 if out of range |
| B8 | Dynamic | =1 if secondary/tertiary |
| B9 | Dynamic | =1 if tare in system |
| B10 | Dynamic | =1 if tare is keyed |
| B11 | Dynamic | =00 if MODE=GROSS =01 if MODE=NET =10 if MODE=TARE =11 (<i>not used</i>) |
| B12 | Dynamic | =00 if UNITS=PRIMARY =01 if UNITS=SECONDARY =10 if UNITS=TERTIARY =11 (<i>not used</i>) |
| B13 | Configuration | =00 (<i>not used</i>) =01 if current DSPDIV=1 =10 if current DSPDIV=2 =11 if current DSPDIV=5 |
| B14 | Configuration | =00 (<i>not used</i>) =01 if primary DSPDIV=1 =10 if primary DSPDIV=2 =11 if primary DSPDIV=5 |
| B15 | Configuration | =00 (<i>not used</i>) =01 if secondary DSPDIV=1 =10 if secondary DSPDIV=2 =11 if secondary DSPDIV=5 |
| B16 | Configuration | =00 (<i>not used</i>) =01 if tertiary DSPDIV=1 =10 if tertiary DSPDIV=2 =11 if tertiary DSPDIV=5 |

Table 6-11. Custom Stream Format Identifiers

| Format Identifier | Defined By | Description |
|--------------------------------|---------------|--|
| B17 | Configuration | =000 if current DECPNT=8888800 =001 if current DECPNT=8888880 =010 if current DECPNT=8888888 =011 if current DECPNT=888888.8 =100 if current DECPNT=88888.88 =101 if current DECPNT=8888.888 =110 if current DECPNT=888.8888 =111 if current DECPNT=88.88888 |
| B18 | Configuration | =000 if primary DECPNT=8888800 =001 if primary DECPNT=8888880 =010 if primary DECPNT=8888888 =011 if primary DECPNT=888888.8 =100 if primary DECPNT=88888.88 =101 if primary DECPNT=8888.888 =110 if primary DECPNT=888.8888 =111 if primary DECPNT=88.88888 |
| B19 | Configuration | =000 if secondary DECPNT=8888800 =001 if secondary DECPNT=8888880 =010 if secondary DECPNT=8888888 =011 if secondary DECPNT=888888.8 =100 if secondary DECPNT=88888.88 =101 if secondary DECPNT=8888.888 =110 if secondary DECPNT=888.8888 =111 if secondary DECPNT=88.88888 |
| B20 | Configuration | =000 if tertiary DECPNT=8888800 =001 if tertiary DECPNT=8888880 =010 if tertiary DECPNT=8888888 =011 if tertiary DECPNT=888888.8 =100 if tertiary DECPNT=88888.88 =101 if tertiary DECPNT=8888.888 =110 if tertiary DECPNT=888.8888 =111 if tertiary DECPNT=88.88888 |
| <wspec [-] [0] digit[.].digit> | Scale weight | Weight for the source scale. <i>wspec</i> is defined as follows: <i>wspec</i> Indicates whether the weight is the current displayed weight (W, w), gross (G, g), net (N, n), or tare (T, t) weight. Upper-case letters specify right-justified weights; lower-case are left-justified. Optional /P, /S, or /T suffixes can be added before the ending delimiter (>) to specify weight display in primary (/P), secondary (/S), or tertiary (/T) units. [-] Enter a minus sign (-) to include sign for negative values. [0] Enter a zero (0) to display leading zeroes. digit[.].digit The first digit indicates the field width in characters. Decimal point only indicates floating decimal; decimal point with following digit indicates fixed decimal with <i>n</i> digits to the right of the decimal. Two consecutive decimals send the decimal point even if it falls at the end of the transmitted weight field. |
| <CR> | — | Carriage return |
| <LF> | — | Line feed |

Table 6-11. Custom Stream Format Identifiers

7.0 Print Formatting

The CW-90/90X provides seven print formats, GFMT, NFMT, ACC.FMT, STRM.FM, BUS.FMT, HDRFMT1 and HDRFMT2. These determine the format of the printed output when the PRINT key is pressed or when a KPRINT EDP command is received. The GFMT and NFMT will print to all ports assigned as DEMAND in the THRESH parameter, based on whether a tare is in the indicator. The ACCFMT will print to all DEMAND ports when the ACCUM is displayed. The SFMT will be sent as a STREAM if THRESH is set to STREAM on any port. The HDRFMTs must be called from another format.

Each print format can be customized to include up to 300 characters of information, such as company name and address, on printed tickets. You can use the indicator front panel (PFORMAT menu), EDP commands, or the Revolution® III configuration utility to customize the print formats.

NOTES: Print formats are limited to 300 characters. The display will only show capital letters, press the down arrow to view the ASCII character decimal value on the second menu level.

7.1 Print Formatting Commands

Table 7-1 lists commands you can use to format the gross, net and count print formats. Commands included in the format strings must be enclosed between < and > delimiters. Any characters outside of the delimiters are printed as text on the ticket. Text characters can include any ASCII character that can be printed by the output device.

| Command | Description |
|---------|--|
| <G> | Gross weight in displayed units |
| <N> | Net weight in displayed units |
| <T> | Tare weight in displayed units |
| <A> | Accumulated weight in displayed units |
| <CKS> | Status of over/under/accept. O=Over, U=Under, A=Accept |
| <CKOV> | Over value |
| <CKUV> | Under value |
| <CKTV> | Target value |
| <CKID> | Loaded ID number |
| <CKD1> | Description 1 |
| <CKD2> | Description 2 |
| <CKU> | Units |
| <CKT> | Tare |
| <AC> | Number of accumulator events (5-digit counter) |

Table 7-1. Print Format Commands

| Command | Description |
|--|---|
| <AD> | Date of last accumulator event |
| <AT> | Time of last accumulator event |
| <UID> | Unit ID number |
| <CN> | Consecutive number |
| <NLnn> | New line (nn = number of termination (<CR/LF> or <CR>) characters)* |
| <SPnn> | Space (nn = number of spaces)* |
| <SU> | Toggle weight data format (formatted/unformatted)** |
| <TI> | Time |
| <DA> | Date |
| <TD> | Time & Date |
| <H1> | Header 1 |
| <H2> | Header 2 |
| Gross, net, and tare weights are 9 digits in length, including sign (10 digits with decimal point), followed by a space and a two-digit units identifier. Total field length with units identifier is 12 (or 13) characters. | |
| ID and consecutive number (CN) fields are 1–6 characters in length, as required. | |
| * If nn is not specified, 1 is assumed. Value must be in the range 1–99. | |
| ** After receiving an SU command, the indicator sends unformatted data until the next SU command is received. Unformatted data omits decimal points, leading and trailing characters. | |

Table 7-1. Print Format Commands

The default GFMT and NFMT print formats use only the new line (<NL>) command and the commands for gross, net, and tare weights in displayed units (<G>, <N>, and <T>). The default CW-90/90X print formats are shown in Table 7-2:

| Format | Default Format String | Sample Output |
|--------|-----------------------|------------------|
| GFMT | <G> GROSS<NL> | 2046.81 lb GROSS |
| NFMT | <G> GROSS<NL> | 4053.1 lb GROSS |
| | <T> TARE<NL> | 15.6 lb TARE |
| | <N> NET<NL> | 4037.5 lb NET |

Table 7-2. GFMT and NFMT Formats

NOTES:

- ID numbers included in the print format string (<UID> command) must be set using the UID EDP command.
- The 300-character limit of each print format

string includes the output field length of the print formatting commands, not the command length. For example, if the indicator is configured to show a decimal point, the <G> command generates an output field of 13 characters: the 10-character weight value (including decimal point), one space, and a two-digit units identifier.

7.2 Customizing Print Formats

The following sections describe procedures for customizing the GFMT, NFMT and CFMT formats using the EDP port, the front panel (PFORMT menu), and the Revolution® III configuration utility.

7.2.1 Using the EDP Port

With a personal computer, terminal, or remote keyboard attached to the CW-90/90X EDP port, you can use the EDP command set to customize the print format strings.

To view the current setting of a format string, type the name of the string (GFMT or NFMT) and press **ENTER**. For example, to check the current configuration of the GFMT format, type GFMT and press **ENTER**. The indicator responds by sending the current configuration for the gross format:

```
GFMT=<G> GROSS<NL>
```

To change the format, use the GFMT or NFMT EDP command followed by an equals sign (=) and the modified print format string. For example, to add the name and address of a company to the gross format, you could send the following EDP command:

NOTE: Indicator must be placed in the config mode with *CONFIG* shown on the display.

```
GFMT=FINE TRANSFER CO<NL>32400 WEST  
HIGHWAY ROAD<NL>SMALLTOWN<NL2><G>  
GROSS<NL>
```

A ticket printed using this format might look like the following:

```
FINE TRANSFER CO  
32400 WEST HIGHWAY ROAD  
SMALLTOWN
```

```
1345 lb GROSS
```

7.2.2 Using the Front Panel

If you have no access to equipment for communication through the EDP port or are working at a site where such equipment cannot be used, you can use the PFORMT menu (see Figure 7-1) to customize the print formats.

Using the PFORMT menu, you can edit the print format




Figure 7-1. PFORMT Menu, Showing Alphanumeric Character Entry Procedure

7.2.3 Using Revolution® III

The Revolution III configuration utility provides a print formatting grid with a tool bar. The grid allows you to construct the print format without the formatting commands (<NL> and <SP>) required by the front panel or EDP command methods. Using Revolution III, you can type text directly into the grid, then select weight value fields from the tool bar and place them where you want them to appear on the printed ticket.

Figure 7-2 shows an example of the Revolution III print formatting grid.




Figure 7-2. Revolution III Print Format Grid

8.0 WLAN Installation Instructions

NOTE: Before installing this option, you must contact your IT administrator to obtain network communication protocol codes and have a RS-232 communications cable or regular comm port cable available to run between your PC and the indicator while installing and setting up the wireless network.

The optional Lantronix® WiPort™ (WLAN - Wireless Local Area Network) wireless networking device can be installed inside the CW-90/90X for real-time data transmission to warehouse management systems. The Windows®-based configuration software, DeviceInstaller™ is required for installation and setup and is available on the CD that comes with the kit. The WLAN option can be factory installed or can be purchased separately and installed on site.

The wireless LAN option comes in a kit containing the following items:

- Pluggable wireless board (PN 97789)
- Antenna (PN 98357)
- Standoffs (PN 95356)
- CD containing Lantronix information (PN 72763)




Figure 8-1. WLAN board

8.1 Enclosure Disassembly

The indicator enclosure must be opened to install the WLAN option card and antenna and to connect cables for the installed option card.



Warning

Before opening the unit, ensure the power cord is disconnected from the power outlet.

1. Disconnect power to the indicator.
2. Place the indicator face-down on an antistatic work mat.
3. Remove the screws that hold the backplate to the enclosure body, then lift the backplate away from the enclosure and set it aside.

8.2 Installing the WLAN Option Card



Caution

Option cards are not hot-pluggable. Disconnect power to the unit before installing the WLAN option card.

1. Ensure that power has been disconnected to the indicator. Remove backplate as described in the previous section.
2. Carefully align the WLAN option card onto the J5 connector on the CW-90/90X CPU board.
3. Press down firmly to seat the option card in the CPU board connector.
4. Use the standoffs provided in the option kit to secure the option card to the mounting holes on the CPU board.
5. Set up the WLAN configuration parameters as explained on Section 8.6 on page 56.
6. Make connections to the option card as required. Use cable ties to secure loose cables inside the enclosure. When installation and configuration is complete, reassemble the enclosure (refer to Section 2.8 on page 7).

8.3 Mounting the Antenna

1. If the antenna is not already connected, screw it in place as shown in Figure 8-2.



Figure 8-2. Antenna installed on card

2. Place the antenna through the large cord grip, closest to the option card. It is recommended for the antenna to extend out of the cord grip so that approximately one inch (1") is exposed. (see Figure 8-3).



Figure 8-3. WLAN antenna

3. Tighten the cord grip. Option cards are recognized when the unit is powered on.

8.4 Wireless Configuration via Serial Mode

You must configure the WLAN card so that it can communicate on your network. WiPort (WLAN) is configurable using a PC and a terminal program (like Windows XP Hyperterminal) to access the device serial port locally. To configure the WiPort (WLAN option), connect a serial cable from the J2 connector of the installed WLAN option card to a PC.

8.5 Jumpers

There are two configuration jumpers located on the WLAN option board. See Figure 8-4 below. These jumpers must be set to the CFG position to configure the WLAN option.




Figure 8-4. Jumpers location

Once the configuration jumpers are in the CFG position, continue with WLAN Card Configuration to make the necessary settings for the WLAN option.

NOTE: Not all devices display information in the same manner and depending on your IT department's software choice for configuring the WLAN option, the screens displayed may be different.

If using Lantronix DeviceInstaller, you may access additional information and download the latest version from their web site at: www.lantronix.com.

8.6 WLAN Card Configuration

1. Select the Hyperterminal program on the PC.
2. Enter a name and choose an icon for the connection, then click OK.



Figure 8-5. Hyperterminal connection description screen

3. Select a *Connect To* option. Select the comm port you have connected your serial cable to and click OK.



Figure 8-6. Connect To screen

4. Comm port properties must be set as shown in the following screen.




Figure 8-7. Comm Port Properties screen

The WLAN configuration port uses the following settings:

- Baud Rate: 9600
- 8 Bits
- No parity
- 1 Stop Bit
- No Flow Control

5. Make the changes and click OK to save the changes.
6. Reset the WLAN option card by pressing the manual reset button shown in Figure 8-8, and immediately upon release, enter three lowercase x characters (xxx) at the same time.

Manual Reset Button




Figure 8-8. Manual Reset Button location on WLAN option card

NOTE: The easiest way to connect is to hold down the **x** key on the PC's keyboard until the manual reset button is released and the PC screen displays the MAC address and software version as shown in Figure 9. This must be done within three seconds of resetting the WLAN option.

Upon a successful connection, the following information is displayed.




Figure 8-9. Display Information for Setup Mode

7. To enter Setup Mode, press **Enter** within *five* seconds. Note that the connection will fail if **Enter** is not pressed within the *five* second time limit. The configuration settings display, followed by the setup menu options. If this happens, repeat Step 5.
8. Select an option on the menu by entering the number of the option in *Your Choice?* field and press **Enter**. In

this case, we're setting up the WLAN options so press 4 and press **Enter** as shown in Figure 12.




Figure 8-10. Change Setup Screen

View the current configuration by pressing **Enter** from the Change Setup menu. To enter a value for a parameter, type the value and press Enter. To confirm a current value, press Enter (without inputted parameters).

9. Enter the desired Topology for the WLAN option.




Figure 8-11. Topology Screen

The two choices are:

- 0 = Infrastructure
- 1 = AdHoc.

Select 0 for your choice and press **Enter**.

10. The next menu choice is Network Name as shown below.





Figure 8-12. Network Name Screen

Enter your wireless network name as your menu choice and press **Enter**. This identifies the network that the wireless option will run on.

11. The next step is to select a level of security as shown in Figure 15.



```
Change Setup:
 0 Server
 1 Channel 1
 2 Channel 2
 4 WLAN
 5 Expert
 6 Security
 7 Factory defaults
 8 Exit without save
 9 Save and exit          Your choice ? 4

Topology 0=Infrastructure, 1=AdHoc (0) ? 0
Network name (SSID) (    ) ? (    )
Security 0=none, 1=WEP, 2=WPA (1) ?
```


Figure 8-13. Security Level Select Screen

Security levels include:

- 0 = None
- 1 = WEP (Equivalency Protection)
- 2 = WPA

Select **1** and press **Enter**.

12. The next step is to set the authentication level for the configuration as shown below.



```
Change Setup:
 0 Server
 1 Channel 1
 2 Channel 2
 4 WLAN
 5 Expert
 6 Security
 7 Factory defaults
 8 Exit without save
 9 Save and exit          Your choice ? 4

Topology 0=Infrastructure, 1=AdHoc (0) ? 0
Network name (SSID) (    ) ? (    )
Security 0=none, 1=WEP, 2=WPA (1) ? 1
Authentication 0=open/none, 1=shared (0) ?
```

Figure 8-14. Authentication Screen

Authentication choices are:

- 0 = open/none
- 1 = Shared

Select **0** = open/none and press **Enter**.

13. Select the correct encryption next. Choices are WEP64 and WEP128 as shown below. Select 1 = WEP64 as the default parameter and press Enter.




Figure 8-15. Encryption Screen

14. Next, it asks to display current key? Press N and press Enter.




Figure 8-16. Display Current Screen

Select Yes (Y) for the “display current key” option. This prompt shows the currently configured key/passphrase.




Figure 8-17. Change Key Screen

Select the data rate and press Enter.

15. The screen automatically goes to end the screen which gives the choice to Save and Exit (9) and is shown below. By selecting that choice, and pressing **Enter**, the WLAN parameters are saved and the screen becomes greyed out as is shown below.




Figure 8-18. Save and Exit Screen

Once all of the data is saved, you must switch the jumpers back to the OFF position (Figure 5) to exit out of the configuration mode.

Now you can access and view all wireless data on the PC.

8.7 Enclosure Reassembly

Once cabling is complete, position the backplate over the enclosure and reinstall the backplate screws. Use the torque pattern shown in the indicator's manual to prevent distorting the backplate gasket.

8.8 WiPort Wireless Specifications

| Category | | Description |
|---------------------------------|-------------------------------|--|
| Network Standards | | IEEE 802.11b; IEEE 802.11g |
| Frequency Range | | 2.412 - 2.484 GHz |
| Antenna Connector | | 1, no diversity supported |
| Data Rates | | 1, 2, 5.5, 11Mbps (802.11b) 6, 9, 12, 18, 24, 36, 48, 54Mbps (802.11g) |
| Radio | Number of Selectable Channels | Up to 14 channels. Profiles available will include USA, France, Japan, Spain, Canada and "other" (multiple countries). |
| | Modulations | OFDM, DSSS, DBPSK, DQPSK, CCK, 16QAM, 64QAM |
| | Antenna Connector | 1 |
| Security | | WEP 64/128, WPA-PSK, TKIP, AES end-to-end encryption |
| Maximum Receive Level | | -10 dBm (with PER < 8%) |
| Receiver Sensitivity | | -72 dBm for 54Mbps -87 dBm for 11Mbps -89 dBm for 5.5Mbps -90 dBm for 2.0Mbps -92 dBm for 1.0Mbps |
| WLAN Power and Link LED Current | | Max: 4 mA |

Table 8-1. WiPort Wireless Specifications

8.9 WiPort Technical Data

| Category | Description |
|-----------------------------|---|
| CPU, Memory | Lantronix DSTni-EX 186 CPU, 256 KB zero wait state on chip SRAM, 2048 KB flash, 16 KB Bott ROM |
| Firmware | Upgradeable via TFTP and serial port |
| Reset Circuit | Reset In is low active. Minimum reset pulse width is 2 ms at IIL = -500 aA |
| Serial Interface | CMOS (Asynchronous) 3.3V-level signals Rate is software selectable (300 bps to 921600 bps) |
| Serial Line Formats | 7 or 8 data bits, 1-2 stop bits, parity: odd, even, none |
| Modem Control | DTR, DCD |
| Flow Control | XON/XOFF (software), CTS/RTS (hardware), none |
| Network Interface | Wireless 802.11b, 802.11g and 10/100 Ethernet |
| Protocols Supported | ARP, UDP, TCP, Telnet, ICMP, SNMP, DHCP, BOOTP, Auto IP, HTTP, SMTP, TFTP |
| Media Access Control | CSMA/CA with ACK |
| Frequency Range | 2.412-2.484 GHz |
| Range | Up to 328 feet (100m) line of sight |
| Modulation Techniques | OFDM DSSS CCK DQPSK DBPSK 64 QAM 16 QAM |
| Transmit Output Power | 14 dBm + 1.5 dBm/-1.0 dBm |
| Peak Supply Current at 3.3V | 650 mA |
| Management | Internal web server, SNMP (read only) Serial login, Telnet login DeviceInstaller software |
| Security | Password protection, locking features, 64/128 bit WEP, WPA-PSK, End-to-End AES |
| Internal Web Server | Serves web pages Storage capacity: 1.2 MB |
| Weight | 29 grams |
| Material | Metal shell |
| Temperature | Operating range: -30° C to +70° C (-22° F to 158° F) Storage range: -40° C to +85° C (-40° F to +185° F) |
| Warranty | 2-year limited warranty |
| Included Software | Windows® 98/NT/2000/XP based DeviceInstaller configuration software and Windows based Comm Port Redirector, DeviceInstaller, Web-Manager Lantronix web site: http://www.lantronix.com/ |

Table 8-2. WiPort Technical Data

8.10 WiPort Disclaimer

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Re-orient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/tv technician for help

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device is intended only for OEM integrators. The OEM integrator should be aware of the following important issues.

Labeling of the End Product

The label of the end product integrating this module must clearly indicate that the end product contains an FCC approved RF module. The format of such statement could be *Contains Transmitter with FCC ID: R68WIPORTG* or something similar.

RSS-GEN Sections 7.1.4 and 7.1.5 Statement for Devices with Detachable Antennas

This device has been designed to operate with the antennas listed in the certificate, and having a maximum gain of 5 dB. Antennas not included in this list or having a gain greater than 5 dB are strictly prohibited for use with this device. The required antenna impedance is 50 ohms.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that required for successful communication.

Integration Note

(a) This module is authorized under limited module approval specified to mobile host equipment. So, the antenna must be installed such that 20 cm is maintained between the antenna and the user.

(b) The transmitter module may not be co-located with any other transmitter or antenna.

As long as the two conditions above are met, further transmission testing will not be required. However, the OEM integrator is still responsible for testing their end product for any additional compliance requirements required with this module installed (for example, digital device emission, PC peripheral requirements, etc).

NOTE: In the event that these conditions cannot be met (for example) certain laptop configurations, general purpose PCMCIA or similar card, or location with another transmitter, then the FCC authorization is no longer considered valid and the FCC ID cannot be used on the final product (including the transmitter) and obtaining a separate FCC authorization.

NOTE: Changes or modifications to this device not explicitly approved by Lantronix will void the user's authority to operate this device.

9.0 Appendix

9.1 Error Messages

If an error code appears on the display, use the information in Table 9-1 as a troubleshooting guide. If you cannot clear the error, call RLWS Service for assistance.




| Error Display | Description | Solution |
|---|---|--|
|  | Over range | <ul style="list-style-type: none"> Check load cell wiring, including sense jumpers. Check configuration, including number of grads, channel selection, display divisions. Check calibration, including W ZERO and W SPAN values. Check for scale binding or damage. Check for proper excitation voltage. Call RLWS Service for assistance. |
|  | Under range | |
|  | A/D out of range | |
| CHKERR - BATTERY BACK LOST | Battery Error | Press ENTER after replacing the battery to restore defaults to battery backed storage. |
| CNT-BY | Count By error | |
| E A/D | A/D physical error | Call Rice Lake Weighing Systems (RLWS) Service. |
| EEEROM | EEPROM physical error | |
| EVIREE | Virgin EEPROM | Use TEST menu to perform DEFLT (restore defaults) procedure, then recalibrate load cells. |
| EPCKSM | Parameter checksum error | |
| EACKSM | A/D calibration checksum error | A/D converter requires recalibration. Call RLWS Service. |
| EFCKSM | Printer format checksum error | Call RLWS Service. |
| ELCKSM | Load cell calibration checksum error | Recalibrate load cells. |
| EIDATA | Internal RAM checksum error | Call RLWS Service. |
| E REF | A/D reference error | A/D converter requires recalibration. Call RLWS Service. |
| ERROR | Internal program error | Check configuration. Run XE command (see Section 9.2 on page 66) to determine error type. Call RLWS Service if unable to clear error by cycling power or if error reoccurs. |
| HWFERR | Hardware error | Reboot the unit. Call RLWS Service if unable to clear error by cycling power or if error reoccurs. |
| OVERFL | Overflow error | Weight value too large to be displayed. |
| RANGE | GRADS > 100,000 WVAL > 100,000 | Only shows up in Config mode. |
| EEPERR | EEPROM error | Call Rice Lake Weighing Systems (RLWS) for service |
| VERSION UPDATED | Core has been updated or memory has been corrupted. | Press the ENTER key. If the message persists, call RLWS for service. |

Table 9-1. CW-90/90X/CW-90/90XX Error Messages

9.2 Using the XE EDP Command

The XE EDP command can be used to remotely query the CW-90/90X for the error conditions shown on the front panel. The XE command returns a 5-digit number in the format:

xxxxx yyyy

where xxxxx contains a decimal representation of any existing error conditions as described in Table 9-2.

If more than one error condition exists, the number returned is the sum of the values representing the error conditions. For example, if the XE command returns the number 1040, this value represents the sum of an A/D reference error (1024) and an A/D calibration checksum error (16).

| XE Error Code | Description | XEH Hex Value |
|----------------------|------------------|---------------|
| 1 | VIRGERR | 0x00000001 |
| 2 | PARMCHKERR | 0x00000002 |
| 4 | LOADCHKERR | 0x00000004 |
| 8 | PRINTCHKERR | 0x00000008 |
| 16 | ENVRAMERR | 0x00000010 |
| 32 | ENVCRCERR | 0x00000020 |
| 64 | BATTERYERR | 0x00000040 |
| 32768 | GRAVERR | 0x00008000 |
| 65536 | ADPHYSICALERR | 0x00010000 |
| 131072 | TAREERR | 0x00020000 |
| 262144 | EACCOVER | 0x00040000 |
| 524288 | STRINGERR | 0x00080000 |
| 1048576 | RESERVED_PF | 0x00100000 |
| 2097152 | RTCERR | 0x00200000 |
| 4194304 | MISSINGHWERR | 0x00400000 |
| 8388608 | CFGCONFLICTERR | 0x00800000 |
| 16777216 | UNRECOVERABLEERR | 0x01000000 |
| 0x10000 - 0x80000000 | | Reserved |

Table 9-2. Error Codes Returned on XE Command

9.3 Status Messages

Two EDP commands, P and ZZ, can be used to provide status about the indicator. These commands are described in the following sections.

9.3.1 Using the P EDP Command

The P EDP command returns the current displayed weight value to the EDP port, along with the units identifier. If the indicator is in an underrange or overload condition, the weight value is replaced with &&&&& (overload) or ::::: (underrange).

9.3.2 Using the ZZ EDP Command

The ZZ EDP command can be used to remotely query which annunciators are currently displayed on the indicator front panel. The ZZ command returns the currently displayed weight and a decimal number representing the LED annunciators currently lit. The format of the returned data is:

wwwwwww uu zzz

where wwwwww uu is the current displayed weight and units, zzz is the annunciator status value (see Table 9-3). If more than one annunciator is lit, the second number returned is the sum of the values representing the active annunciators.

Example: If the annunciator status value returned on the ZZ command is 145, the gross, standstill, and lb annunciators are lit. 145 represents the sum of the values for the standstill annunciator (128), gross mode annunciator (16), and the lb/primary units annunciator (1).

| Decimal Value | Annunciator |
|---------------|--------------------|
| 1 | lb/primary units |
| 2 | kg/secondary units |
| 4 | Count |
| 8 | Tare entered |
| 16 | Gross |
| 32 | Net |
| 64 | Center of zero |
| 128 | Standstill |

Table 9-3. Status Codes Returned on the ZZ Command

9.4 Continuous Output (Stream) Format

Figure 9-1 shows the continuous output format sent to the CW-90/90X EDP or printer port when the STREAM parameter (SERIAL menu) is set to either EDP or PRN.




Figure 9-1. Continuous Output Data Format

9.5 Digital Filtering

The CW-90/90X uses averaged digital filtering to reduce the effect of vibration on weight readings. Adjustable threshold and sensitivity functions allow quick settling by suspending filter averaging, allowing the weight reading to jump to the new value. Figure 9-2 shows the digital filter parameters on the CONFIG menu.




Figure 9-2. Digital Filtering Parameters on the Configuration (CONFIG) Menu




Figure 9-3. Flow Diagram for CW-90/90X Digital Filters

9.5.1 DIGFLx Parameters

The first three digital filtering parameters, DFLTR1, DFLTRL2, and DFLTR3, are configurable filter stages that control the effect of a single A/D reading on the displayed weight. The value assigned to each parameter sets the number of readings received from the preceding filter stage before averaging (see Figure 9-3).

The overall filtering effect can be expressed by adding the values assigned to the three filter stages:

$$\text{DFLTR1} + \text{DFLTR2} + \text{DFLTR3}$$

For example, if the filters are configured as DFLTR1=4, DFLTR2=8, DFLTR3=8, the overall filtering effect is 20 (4 + 8 + 8). With this configuration, each A/D reading has a 1-in-20 effect on the displayed weight value. Setting the filters to 1 effectively disables digital filtering.

9.5.2 DFSENS and DFTHR Parameters

The three digital filters can be used by themselves to eliminate vibration effects, but heavy filtering also increases settling time. The DFSENS (digital filter sensitivity) and DFTHR (digital filter threshold) parameters can be used to temporarily override filter averaging and improve settling time:

- DFSENS specifies the number of consecutive scale readings that must fall outside the filter threshold (DFTHR) before digital filtering is suspended.
- DFTHR sets a threshold value, in display divisions. When a specified number of consecutive scale readings (DFSENS) fall outside of this threshold, digital filtering is suspended. Set DFTHR to NONE to turn off the filter override.

9.5.3 Setting the Digital Filter Parameters

Fine-tuning the digital filter parameters greatly improves indicator performance in heavy-vibration environments. Use the following procedure to determine vibration effects on the scale and optimize the digital filtering configuration.

1. In menu mode, set all three digital filters (DFLTR1, DFLTRL2, DFLTR3) to 1. Set DFTHR to NONE. Return indicator to normal mode.
2. Remove all weight from the scale, then watch the indicator display to determine the magnitude of vibration effects on the scale. Record the weight below which all but a few readings fall. This value is used to calculate the DFTHR parameter value in Step 4.

For example, if a heavy-capacity scale produces vibration-related readings of up to 50 lb, with occasional spikes to 75 lb, record

50 lb as the threshold weight value.

3. Place the indicator in menu mode and set the digital filters (DFLTRx) to eliminate the vibration effects on the scale. (Leave DFTHR set to NONE.) Reconfigure as necessary to find the lowest effective values for the DFLTRx parameters.
4. With optimum values assigned to the DFLTRx parameters, calculate the DFTHR parameter value by converting the weight value recorded in Step 2 to display divisions:

$$\text{threshold_weight_value} / \text{DSPDIV}$$

In the example in Step 2, with a threshold weight value of 50 lb and a display division value of 5lb: $50 / 5\text{lb} = 10\text{DD}$. DFTHR should be set to 10DD for this example.

5. Finally, set the DFSENS parameter high enough to ignore transient peaks. Longer transients (typically caused by lower vibration frequencies) will cause more consecutive out-of-band readings, so DFSENS should be set higher to counter low frequency transients. Reconfigure as necessary to find the lowest effective value for the DFSENS parameter.

9.5.4 Audit Trail Support

Audit trail support provides tracking information for configuration and calibration events. To prevent potential misuse, all configuration and calibration changes are counted as change events.

Use the Audit menu or Revolution III to display audit trail information. This includes the legally relevant (LR) version number (software version for the code that provides audit trail information), a calibration count and, if REGULA=NTEP, a configuration count. The exact format of the information shown depends on the regulatory agency specified for the REGULA parameter (FEATUR menu).

Audit trail information can be printed from Revolution III or by sending the DUMPAUDIT serial command.

9.6 Regulatory Mode Functions

The function of the front panel **TARE** and **ZERO** keys depends on the value specified for the **REGULAT** parameter on the **FEATURE** menu. Table 9-4 describes the function of these keys for the **NTEP**, **CANADA**, **OIML**, and **NONE** regulatory modes. **TARE** and **ZERO** key functions are configurable when the **REGULAT** mode is set to **INDUST** (see Table 9-5 on page 69).

| REGULAT Parameter Value | Weight on Scale | Tare in System | Front Panel Key Function | |
|----------------------------|------------------|----------------|--------------------------|--|
| | | | TARE | ZERO |
| NTEP | zero or negative | no | <i>no action</i> | ZERO |
| | | yes | CLEAR TARE | |
| | positive | no | TARE | |
| | | yes | TARE | |
| CANADA | zero or negative | no | <i>no action</i> | ZERO |
| | | yes | CLEAR TARE | |
| | positive | no | TARE | |
| | | yes | <i>no action</i> | |
| OIML | zero or negative | no | <i>no action</i> | ZERO |
| | | yes | CLEAR TARE | ZERO and CLEAR TARE |
| | positive | no | TARE | ZERO |
| | | yes | TARE | ZERO and CLEAR TARE if weight is within ZRANGE. <i>No action if weight is outside of ZRANGE</i> |
| NONE | zero or negative | no | TARE | ZERO |
| | | yes | CLEAR TARE | |
| | positive | no | TARE | |
| | | yes | CLEAR TARE | |

Table 9-4. TARE and ZERO Key Functions for REGULAT Parameter Settings

Table 9-5 lists the subparameters available when configuring a scale using **INDUST** mode. The table includes the default values of the **INDUST** subparameters and the effective (not configurable) values used by the **NTEP**, **CANADA**, **OIML**, and **NONE** regulatory modes.

| REGULAT / INDUST Parameter | | REGULAT Mode | | | | |
|----------------------------|---|--------------|------------|------------|------------|------------|
| Parameter Name | Text Prompt | INDUST | NTEP | CANADA | OIML | NONE |
| SNPSHOT | Display or Scale weight source | DISPLAY | DISPLAY | DISPLAY | DISPLAY | SCALE |
| HTARE | Allow tare in display hold | NO | NO | NO | NO | YES |
| ZTARE | Remove tare on ZERO | NO | NO | NO | YES | NO |
| KTARE | Always allow keyed tare | YES | YES | NO | YES | YES |
| MTARE | Multiple tare action | REPLACE | REPLACE | NOTHING | REPLACE | REMOVE |
| NTARE | Allow negative tare | NO | NO | NO | NO | YES |
| CTARE | Allow CLEAR key to clear tare/ accumulator | YES | YES | NO | NO | YES |
| PRTMOT | Allow print while in motion | NO | NO | NO | NO | YES |
| PRTPT | Add PT to keyed tare print | NO | NO | YES | YES | NO |
| PRTHLD | Print during display hold | NO | NO | NO | NO | YES |
| HLDWGH | Allow weigh during display hold | NO | NO | NO | NO | YES |
| MOTWGH | Allow weighment in motion | NO | NO | NO | NO | NO |
| OVBASE | Zero base for overload calculation | CALIB ZERO | CALIB ZERO | CALIB ZERO | SCALE ZERO | CALIB ZERO |

Table 9-5. REGULAT / INDUST Mode Parameters, Comparison with Effective Values of Other Modes

9.7 Updating CW-90/90X Firmware

To update firmware of the CW-90/90X, you must have Revolution III installed and a .hex file on your computer. Visit www.ricelake.com to download this free configuration software and the latest .hex file.

NOTE: If the .hex file is the same version as is currently in the indicator, the firmware update will not reset the configuration. This is helpful if the firmware becomes corrupt and you want to reload the same firmware. However, it is always recommended that configuration be backed up in Revolution III to avoid any data loss.

1. Unplug power to the CW-90/90X and remove the back plate.
2. Wire the serial cable to the CW-90/90X's Port 1. Refer to Table 9-6 for cable connection settings.

| DB9 Cable | | | | CW-90/90X Connector (J2) | | |
|-----------|--------|--------|---------------------|--------------------------|-------------|--------|
| Pin/Color | Signal | In/Out | Description | Pin | Description | In/Out |
| 1/Brown | DCD | In | Data Carrier Detect | NC | NA | NA |
| 2/Red | RxD | In | Receive Data | 3 | Tx | Out |
| 3/Orange | TxD | Out | Transmit Data | 4 | Rx | In |
| 4/Yellow | DTR | Out | Data Terminal Ready | 5 | DTR | In |
| 5/Green | GND | ----- | Ground | 1 or 2 | Gnd | ----- |
| 6/Blue | DSR | In | Data Set Ready | NC | NA | NA |
| 7/Purple | RTS | Out | Request to Send | 6 | RTS | In |
| 8/Gray | CTS | In | Clear to Send | NC | NA | NA |
| 9/Black | RI | In | Ring Indicator | NC | NA | NA |

Table 9-6. Cable connection settings

3. Install jumpers on JP3 and JP4 as shown in Figure 9-4.




Figure 9-4. Jumpers installed on JP3 and JP4

4. Plug in power to the CW-90/90X and press the indicator's Power button.
5. With Revolution III open, begin a new configuration file for the CW-90/90X.
6. Click Update CW90 Firmware.



Figure 9-5. Revolution III CW-90/90X screen.

7. The *Rice Lake CW90 Updater* screen appears. Specify the COM port the CW-90/90X is connected to, change the baud rate if needed, and click the ellipses (...) to browse to and select the desired .hex file.




Figure 9-6. Rice Lake CW90 Updater screen

8. Click the Program button. The update will take several moments.
9. When complete, remove the jumpers shown in Figure 9-4 on page 70 and press the Power button to power up the indicator.

9.8 Specifications

| (115 VAC) | | | | |
|-----------|--|-------------------------|---------------|------------------|
| Part # | Capacity | Platform Dimensions | Column Height | Est. Ship Weight |
| 105957 | 5 lb x 0.001 lb (2.5 x 0.0005 kg) 80 x 0.02 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 105958 | 10 lb x 0.002 lb (5 x 0.001 kg) 160 x 0.05 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 105959 | 25 lb x 0.005 lb (10 0.005 kg) 400 x 0.1 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 105960 | 25 lb x 0.005 lb (10 0.005 kg) 400 x 0.1 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |
| 105961 | 50 lb x 0.01 lb (25 x 0.005 kg) 800 x 0.2 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |
| 105962 | 100 lb x 0.02 lb (50 x 0.01 kg) 1600 x 0.5 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |
| (230 VAC) | | | | |
| Part # | Capacity | Platform Dimensions | Column Height | Est. Ship Weight |
| 106123 | 5 lb x 0.001 lb (2.5 x 0.0005 kg) 80 x 0.02 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 106124 | 10 lb x 0.002 lb (5 x 0.001 kg) 160 x 0.05 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 106125 | 25 lb x 0.005 lb (10 0.005 kg) 400 x 0.1 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 106126 | 25 lb x 0.005 lb (10 0.005 kg) 400 x 0.1 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |
| 106127 | 50 lb x 0.01 lb (25 x 0.005 kg) 800 x 0.2 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |
| 106128 | 100 lb x 0.02 lb (50 x 0.01 kg) 1600 x 0.5 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |

Table 9-7. CW-90 specifications

| (115 VAC) | | | | |
|-----------|--|-------------------------|---------------|------------------|
| Part # | Capacity | Platform Dimensions | Column Height | Est. Ship Weight |
| 105963 | 5 lb x 0.001 lb (2.5 x 0.0005 kg) 80 x 0.02 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 105965 | 10 lb x 0.002 lb (5 x 0.001 kg) 160 x 0.05 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 105966 | 25 lb x 0.005 lb (10 0.005 kg) 400 x 0.1 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 105967 | 25 lb x 0.005 lb (10 0.005 kg) 400 x 0.1 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |
| 105968 | 50 lb x 0.01 lb (25 x 0.005 kg) 800 x 0.2 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |
| 105969 | 100 lb x 0.02 lb (50 x 0.01 kg) 1600 x 0.5 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |
| (230 VAC) | | | | |
| Part # | Capacity | Platform Dimensions | Column Height | Est. Ship Weight |
| 106129 | 5 lb x 0.001 lb (2.5 x 0.0005 kg) 80 x 0.02 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 106130 | 10 lb x 0.002 lb (5 x 0.001 kg) 160 x 0.05 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 106131 | 25 lb x 0.005 lb (10 0.005 kg) 400 x 0.1 oz | 10 in x 10 in x 4.25 in | 12 in | 29 lb |
| 106132 | 25 lb x 0.005 lb (10 0.005 kg) 400 x 0.1 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |
| 106133 | 50 lb x 0.01 lb (25 x 0.005 kg) 800 x 0.2 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |
| 106134 | 100 lb x 0.02 lb (50 x 0.01 kg) 1600 x 0.5 oz | 12 in x 12 in x 4.25 in | 12 in | 33 lb |

Table 9-8. CW-90X specifications

Power - AC

| | |
|-------------------|---|
| Line Voltages | 115 or 230 VAC |
| Frequency | 50 or 60 Hz |
| Power Consumption | 1.5 A @ 115 VAC (8W) 0.75 A @ 230 VAC (8W) |
| Fusing | 2.5 A 5 x 20 mm fuse |

Power - DC

| | |
|-------------------|-----------------------------------|
| Line Voltages | 9-36 VDC DC Input |
| Power Consumption | 1.5 A Max |
| Fusing | Internal short circuit protection |

Analog Specifications

| | |
|------------------------------|--|
| Full Scale Input Signal | Up to 22.5 mV |
| Excitation Voltage | +5V single sided 8 x 350 Ω or 16 x 700 Ω load cells |
| Sense Amplifier | Differential amplifier with 4- and 6-wire sensing |
| Analog Signal Input Range | -0.5 mV/V to +4.5 mV/V |
| Analog Signal Sensitivity | 0.3 μ V/graduation minimum, 1.5 μ V/grad recommended |
| Input Impedance | 200 M Ω , typical |
| Noise (ref to input) | 0.3 μ V p-p with digital filters at 4-4-4 |
| Internal Resolution | 8,000,000 counts |
| Display Resolution | 100 000 dd |
| Measurement Rate | Up to 60 measurements/sec |
| Input Sensitivity | 10 nV per internal count |
| System Linearity | Within 0.01% of full scale |
| Zero Stability | 150 nV/ $^{\circ}$ C, maximum |
| Span Stability | 3.5 ppm/ $^{\circ}$ C, maximum |
| Calibration Method | Software, constants stored in EEPROM |
| Common Mode Voltage | -2.35 to +3.45 V, referred to ground |
| Rejection | 130 dB minimum @ 50 or 60 Hz |
| Normal Mode Rejection | 90 dB minimum @ 50 or 60 Hz |
| Input Overload | \pm 12 V continuous, static discharge protected |
| RFI Protection | Signal, excitation, and sense lines protected by capacitor bypass |

Serial Communications

| | |
|--------|---|
| Port 1 | Full duplex RS-232 |
| Port 2 | Full duplex RS-232 |
| Port 3 | Unidirectional active 20 mA current loop |

Operator Interface

| | |
|------------------|--|
| Display | 6-digit LED display. 14-segment, 0.8 in (20 mm) digits |
| LED annunciators | Center of zero, gross, net, tare, preset tare; percent, kg, g, lb, oz |
| Keypad | 21-key flat membrane panel (CW-90) Piezo membrane panel (CW-90X) |

Environmental

| | |
|-----------------------|--|
| Operating Temperature | -10 to +40 $^{\circ}$ C (legal); -10 to +50 $^{\circ}$ C (industrial) |
| Storage Temperature | -25 to +70 $^{\circ}$ C |
| Humidity | 0-95% relative humidity |

Enclosure

| | |
|----------------------|---|
| Enclosure Dimensions | 9.5 in x 6 in x 3.12 in 24 cm x 15 cm x 8 cm |
| Weight | 2.8 Kg (6.1 lb) |
| Rating/Material | UL Type 4X |

Certifications and Approvals



CW-90/90X Indicator

NTEP
CoC Number 08-092
Accuracy Class III/IIIL n_{max} : 10 000



CW-90/90X Scale

NTEP
CoC Number 95-072A2
Accuracy Class III n_{max} : 5 000



(Pending)



(Pending)



Visit www.nsf.org and search by manufacturer.
Or visit the direct link at:
[http://www.nsf.org/Certified/food/
Listings.asp?CompanyName=Rice+Lake%25&](http://www.nsf.org/Certified/food/Listings.asp?CompanyName=Rice+Lake%25&)



(Pending)



Approval No. AM-5710



Caution

Do not use any parts on this scale that
may contain lead.

CW-90/90X Limited Warranty

Rice Lake Weighing Systems (RLWS) warrants that all RLWS equipment and systems properly installed by a Distributor or Original Equipment Manufacturer (OEM) will operate per written specifications as confirmed by the Distributor/OEM and accepted by RLWS. All systems and components are warranted against defects in materials and workmanship for two years.

RLWS warrants that the equipment sold hereunder will conform to the current written specifications authorized by RLWS. RLWS warrants the equipment against faulty workmanship and defective materials. If any equipment fails to conform to these warranties, RLWS will, at its option, repair or replace such goods returned within the warranty period subject to the following conditions:

- Upon discovery by Buyer of such nonconformity, RLWS will be given prompt written notice with a detailed explanation of the alleged deficiencies.
- Individual electronic components returned to RLWS for warranty purposes must be packaged to prevent electrostatic discharge (ESD) damage in shipment. Packaging requirements are listed in a publication, *Protecting Your Components From Static Damage in Shipment*, available from RLWS Equipment Return Department.
- Examination of such equipment by RLWS confirms that the nonconformity actually exists, and was not caused by accident, misuse, neglect, alteration, improper installation, improper repair or improper testing; RLWS shall be the sole judge of all alleged non-conformities.
- Such equipment has not been modified, altered, or changed by any person other than RLWS or its duly authorized repair agents.
- RLWS will have a reasonable time to repair or replace the defective equipment. Buyer is responsible for shipping charges both ways.
- In no event will RLWS be responsible for travel time or on-location repairs, including assembly or disassembly of equipment, nor will RLWS be liable for the cost of any repairs made by others.

THESE WARRANTIES EXCLUDE ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. NEITHER RLWS NOR DISTRIBUTOR WILL, IN ANY EVENT, BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

RLWS AND BUYER AGREE THAT RLWS'S SOLE AND EXCLUSIVE LIABILITY HEREUNDER IS LIMITED TO REPAIR OR REPLACEMENT OF SUCH GOODS. IN ACCEPTING THIS WARRANTY, THE BUYER WAIVES ANY AND ALL OTHER CLAIMS TO WARRANTY.

SHOULD THE SELLER BE OTHER THAN RLWS, THE BUYER AGREES TO LOOK ONLY TO THE SELLER FOR WARRANTY CLAIMS.

NO TERMS, CONDITIONS, UNDERSTANDING, OR AGREEMENTS PURPORTING TO MODIFY THE TERMS OF THIS WARRANTY SHALL HAVE ANY LEGAL EFFECT UNLESS MADE IN WRITING AND SIGNED BY A CORPORATE OFFICER OF RLWS AND THE BUYER.

© 2009 Rice Lake Weighing Systems, Inc. Rice Lake, WI USA. All Rights Reserved.

RICE LAKE WEIGHING SYSTEMS • 230 WEST COLEMAN STREET • RICE LAKE, WISCONSIN 54868 • USA